

User manual

CPS_CPS 10 System



Part Number: NPCPSGB
Revision: J.2

OLDHAM
The Fixed Gas Detection Experts

Copyright 2018 by OLDHAM

June 2018

All rights reserved. Reproduction in any form, in whole or in part, without the express written consent of OLDHAM is strictly prohibited.

The information contained within this manual is true and correct to the best of our knowledge.

Due to ongoing research and development, the specifications of this product may be changed at any time without notice.

OLDHAM.
Rue Orfila
Z.I. Est – CS 20417
F – 62027 ARRAS Cedex
Phone: +33 (0)3 21 60 80 80
Fax: +33 (0) 3 21.60.80.00

We are delighted that you have chosen an **OLDHAM** instrument and would like to thank you for your choice.

We have taken all the necessary measures to ensure that your instrument provides total satisfaction.

Now it is important to read this document carefully.

EXTENT OF RESPONSIBILITY

- * **OLDHAM** declines its responsibility towards any person for material damage, physical injury or death resulting wholly or partly from inappropriate use, installation or storage of its equipment resulting from failure to observe instructions and warnings and/or standards and regulations in force.
- * **OLDHAM** neither supports nor authorises any company, physical or moral person to assume responsibility on behalf of **OLDHAM**, even if it is involved in the sale of **OLDHAM** products.
- * **OLDHAM** cannot be held responsible for direct or indirect damage or be required to pay direct or indirect compensation resulting from the sale or use of any of its products **IF THESE PRODUCTS HAVE NOT BEEN DEFINED AND CHOSEN BY OLDHAM FOR THEIR SPECIFIC USE.**

CLAUSES CONCERNING PROPERTY

- * Drawings, plans, specifications and information included in this document contain confidential information that is the property of **OLDHAM**
- * None of this information may be reproduced, copied, divulged or translated, by physical, electronic or any other means, nor used as the basis for the manufacture or sale of **OLDHAM** equipment or for any other reasons **without prior consent from OLDHAM**

WARNINGS

- * This document is not contractually binding. In the interests of its customers, **OLDHAM** reserves to modify the technical specifications of its equipment without notice, in order to improve its performance.
- * **READ THIS MANUAL CAREFULLY BEFORE FIRST USE OF THE EQUIPMENT:** this manual must be read by any person who is or will be responsible for using, maintaining or repairing this equipment.
- * **This equipment will only provide the announced performance levels if it is used, maintained and repaired according to OLDHAM directives, by OLDHAM personnel or by personnel approved by OLDHAM**
- * **The CPS model is not intended to be used as Life Safety Equipment**

GUARANTEE

2 years guarantee in normal conditions of use on parts and technical labour, return in our workshops, excluding consumables (sensors, filters, etc.)

General Information

Please read the following notice carefully before installation and start-up, paying particular attention to the end-user material safety instructions. This user's guide should be distributed to every individual involved in the installation, operation, maintenance or repair of the CPS system.

The information contained in this manual, the data and technical drawings are correct as of the date of publication. Should questions arise, please contact OLDHAM for additional information.

This manual is designed to provide users with simple and precise information. OLDHAM shall not be responsible or liable for any misinterpretation that may result from the reading of this manual. Although every effort is made to ensure accuracy, this manual may contain unintentional technical inaccuracies.

OLDHAM reserves the right to modify the technical characteristics of its equipment without notice to improve product performance on behalf of its clients.

This manual is a translation of the French original. In case of discrepancy between the French version and any translated version, the French version shall take precedence and shall prevail in all matters pertaining to any relationship between the parties.

i This icon indicates that there is additional useful information for a particular topic.

Safety Warnings

Pictogram labels have been placed on the central controller to call attention to general use safety precautions. These labels are an integral component of the central controller. Replace any label that has peeled off or become illegible. The meanings of these labels are explained below.



Ground terminal



Safety ground terminal



Risk of electric shock



Caution (see accompanying documentation)



European Union (and EEA) only. This icon indicates that in accordance with Directive DEEE (2002/96/CE) and with the regulations specific to your country, this product may not be disposed of with household waste.


Dispose of this product at a collection site intended for electrical waste, for example an official EEE (electrical and electronic equipment) collection site with a recycling or take-back program for authorized products which are available to consumers whose purchases are intended to replace old EEE products with new equivalents.

Failure to comply with regulations for the disposal of this type of waste can be harmful to the environment and to public health, as EEE products typically contain substances that may be dangerous. Your complete cooperation with the disposal of this product will help to ensure a more efficient use of natural resources.

Important Information

The modification of any piece of equipment or the use of any third party parts will automatically void all guarantees.

The central controller is intended to be used for precise applications of a technical nature. Exceeding the indicated values is strictly prohibited.

 WARNING
The installation of this product and all electrical connections should be performed by a qualified professional, in accordance with the manufacturer's specifications and with the standards of authorities in the field.
Failure to observe these warnings may result in serious injury. Exercise great caution, particularly when working with electricity during installation (couplings, network connections).

The use of the unit has been projected for the applications specified in the technical characteristics. Exceeding the indicated values cannot in any case be authorized.

Catalytic sensors are susceptible to poisoning by traces of several substances. This leads to an inhibition which can be permanent or temporary depending on the contaminant, the concentration of the contaminant, the duration of exposure to the contaminant.

Poisoning may result from exposure to substances as:

- silicones (e.g. waterproofing, adhesives, release agents, special oils and greases, certain medical products, commercial cleaning agents)
- tetraethyl lead (e.g. leaded petrol, particularly aviation petrol 'Avgas')
- sulfur compounds (sulfur dioxide, hydrogen sulfide)
- halogenated compounds (R134a, HFO, etc.)
- organo-phosphorus compounds (e.g. herbicides, insecticides, and phosphate esters in fireproof hydraulic fluids)

Oldham recommends regular testing of fixed gas detection installations (read Chapter 6).

Table of Contents

Chapter 1	Overview of the CPS System.....	8
	The CPS central controller.....	10
	Digital addressable modules.....	10
	Digital linking.....	11
	The COM_CPS software application	12
	System Architecture.....	13
Chapter 2	Assembly / Installation.....	14
	Installation of the CPS central controller.....	14
	Mounting the metal wall casing.....	14
	Mounting the 19" 4U rack	14
	Installing digital modules.....	15
	Mounting the CPS 10 sensor module	15
	Mounting the other modules	15
	Connection of modules in a line.....	15
Chapter 3	The CPS Central Measuring Controller.....	16
	View of rack-mounted CPS.....	16
	View of wall-mounted CPS	16
	Central controller electrical connections	17
	Main power supply.....	17
	Grounding the central controller.....	17
	Digital lines	17
	Internal relay dry contacts.....	17
	RS-485 serial link out.....	17
	Overview of the Motherboard.....	19
	Inspecting the digital buses.....	20
	Mini-switches	20
	Internal relay and buzzer	20
	USB / RS-232 serial connectors	21
	RS-485 serial connection (3)	21
	Printer (Optional feature)	22
	The front panel circuit.....	23
	Display Screen.....	23
	Keys.....	23
	Lights	23
	Alarm thresholds	24
	Alarm acknowledgement.....	24
Chapter 4	Digital Modules.....	26
	View of Digital Modules.....	26
	Connecting Digital Modules.....	27
	General topology of the RS-485 network	27
	Wiring the digital network.....	27
	Configuring the communication settings	28
	Slave address	28
	End of line resistor	28
	CPS 10 Detector Module	29
	Available Detector Types	29
	Detector settings.....	29
	External relay module	30
	Relay status lights.....	30
	“Positive/negative” relay security	30
	Relay configuration	31
	Logic Input Module.....	33

Analog Outputs Module	33
Chapter 5 Detailed Menus	36
Menu Tree	36
Start-up Phase	37
Control Menu.....	38
Normal Display	38
Sensor Display.....	38
Events.....	39
Relay Status	39
4-20 mA Output Status	39
Printing.....	40
Acces code.....	40
System Menu.....	41
Line, Module, Relay Action	41
Date and Time	42
Start-up Configuration.....	42
Maintenance Menu.....	43
Simulation	43
Module Verification	44
Bus Faults.....	46
Reset maintenance.....	46
Chapter 6 Maintenance	47
Program transfer.....	47
PC → CPS transfer.....	47
CPS → PC transfer.....	47
Error messages.....	48
Checksum error	48
Testing and calibration of stable installations	49
Sensor replacement.....	49
Semi-automatic calibration.....	50
Manual calibration.....	51
Semi-automatic calibration device	52
Central controller maintenance	53
Lithium battery	53
Back-up battery pack	53
Scrapping of CPS System.....	53
Chapter 7 Technical Specifications.....	55
CPS Central Controller	55
CPS 10 Sensor Module.....	56
CPS RM4 or RM8 Relay Module.....	56
CPS DI16 Logic Inputs Module	56
CPS AO4 Analog Output Module.....	56
Chapter 8 Annexes	57
Chapter 9 UE Declaration of Conformity.....	73

Chapter 1

Overview of the CPS System

The system consists of:


- a central controller for collecting readings and managing alarms;
- various addressable digital modules (sensor modules, relay modules, analog output modules, logic input modules);
- instruments and accessories to process alarms and actions

The CPS system can manage the detection of **10 different gases**, and all detectors are clearly localized and identified.

Data from each sensor is collected in the central controller in less than one second. If gas levels exceed the programmed limits, an audiovisual alarm is triggered and can activate the ventilation system in the affected area of the parking facility.


Use the **COM_CPS software** to program the central controller.

The system status can be quickly verified with semi-automatic calibration for various sensors.




The CPS central controller

CPS : Wall mounted version



CPS : Rack mounted 19" 4U



The central controller is available in a 19" 4U (rack-mount) version or in a wall-mount version. It is designed to control:

- **256 digital modules distributed over 8 lines, with a maximum of 32 modules per line;**
- **256 addressable relays** max. distributed across all relay modules;
- **224 logic inputs** max. distributed across all logic input modules and relay modules.
- **256 analog outputs** max. distributed across 4 analog outputs modules.

Modules are connected through a digital RS-485 network using JBUS/MODBUS protocol.

The central controller connects to 256 toxic sensors, and **runs on only 24 Watts.**






The central controller can be connected to a supervision system via an RS-485 output interface using ModBus protocol.

Optional features include:

- **a battery back-up**, ensuring continual operation in case of a power outage (approx. 1 hour for 50 TOX-type sensors);
- **an integrated printer** (rack-mounted version only) for recording alarms and events;
- **an external printer** (for both rack- and wall-mounted versions).

Digital addressable modules


Various digital addressable modules can be positioned on the same line.

	CPS 10	SENSOR MODULE CO, NO, NO2, CH4, LPG, ...
 	CPS RM4 CPS RM8	RELAY MODULE 4 relays + 2 LI* 8 relays + 2 LI* (*): LI = Logic Input
	CPS AI16	LOGIC INPUT MODULE 16 Logic Inputs
	CPS AO4	ANALOG OUTPUT MODULE 4 opto-isolated 4-20 mA outputs + 2 LI*

Digital linking

Modules are linked in-line via an MPI 22 or equivalent RS-485 double twisted pair cable, at least 0.22 mm² in diameter. One pair supplies power to the module, the second pair is used for the digital RS-485 link.

ISC – personnel should verify that the correct cable has been used in terms of type and capacity.



The **COM_CPS** software application

The **COM_CPS** software application is designed to help configure the CPS central measuring controller on a PC. **COM_CPS** software operations are addressed in a separate manual.

System and Hardware Requirements:

COM_CPS must be installed on a PC running Windows 2000 or Windows XP.

The minimum requirements to install **COM_CPS** are:

- Windows 98 SE, Windows NT, Windows 2000, Windows XP with 256 MB RAM, Windows VISTA.
- A CD-ROM drive
- At least 10 MB of free hard drive space
- A USB connection (cable not included) or a free RS-232 port (specific cable provided) to link the CPS central measuring controller to the PC.

Refer to the **COM_CPS software instructions before installing or using the software, and before programming the central controller.**

The **COM_CPS** software allows you to:

- configure one or more central controller(s) via PC;
- save settings and upload them later to the CPS central controller(s).
- view or modify central controller configuration data within the application.


The **COM_CPS** software can be used to modify the following main configuration settings:

- STEL and TWA calculations
- Predefined status tables printing times
- Conditions that would activate an internal buzzer
- Communication speed for the RS-485 series connection with a master device
- Settings for various sensors and alarm values
- Personalized sensor add-on options
- Delay settings
- Rising edge or falling edge triggers
- Average alarm integration time
- Verification of explosive gasses
- Creation of installation architecture: sensors/relays

COM_CPS

Whenever this sign appears in front of a chapter, the functions described in that chapter are configured with the **COM_CPS** software.

System Architecture




Chapter 2 Assembly / Installation

Installation of the CPS central controller

The CPS central controller should be installed in a dry, climate-controlled area protected from explosive gases and dust. Ideally, the station should be located in a secure, accessible location under surveillance (security office, control room, equipment room ...).


Mounting the metal wall casing

For the wall-mounted CPS in a metal case: *The central controller cover opens at a 90° angle to the left. Make sure to leave adequate space to completely open the cover once the central controller is mounted.*



Mounting the 19" 4U rack

The 19" 4U rack version CPS can be integrated into a rack or a 19" cabinet: *Mount the display at eye level for optimal viewing. Leave at least ½ U (22 mm) on all sides of the central controller to ensure proper ventilation.*



Installing digital modules

Mounting the CPS 10 sensor module


Mount the sensor modules on a flat surface using two screws (Fig. 1).

The modules should be placed in an accessible area, so that maintenance and inspection operations can be conducted as easily and as safely as possible. Nothing in the area should prevent the sensors from obtaining measurements of the ambient environment.

When mounting the sensor module on a vertical surface, position the cable glands on the underside of the module to ensure proper calibration.


Mounting the other modules

The other modules (relay, logic input, analog output) should be mounted on a DIN rail inside of a cabinet or an electric box. (Fig. 2).




Connection of modules in a line

i IMPORTANT: All modules in a line should be wired in-line from the central controller, not in a hub and spoke model.




Chapter 3 The CPS Central Measuring Controller

View of rack-mounted CPS



View of wall-mounted CPS





PART	DESCRIPTION	PART NUMBER
A	CPS WALL CASING	6 514 868
B	CPS RACK 19" 4U	6 514 869
1	CPS FRONT PANEL	6 122 477
2	AP1200 PRINTER	6 114 632
3	BATTERY PACK (OPTIONAL)	6 311 098
4	CPS MOTHERBOARD	6 451 596
5	24V 60W POWER SUPPLY BOARD	6 111 308
6	CPS CENTRAL CONTROLLER DISPLAY	6 133 707
7	RS232 SUB D9 CONNECTOR	6 116 263
8	M16 GROMMET: D5 to D7mm	6 131 166
9	M20 CABLE GLANDS : D6 to D12 mm M20 PE PLASTIC SCREW	6 143 504 6 143 529

Central controller electrical connections

Electrical connections are wired through the central controller MOTHERBOARD and the power supply 24V. For the CPS central controller (wall-mounted version), you must open the casing door to access the electrical panel.

Electrical connections must be done by a qualified professional. Observe all current Directives, notably the European Low Voltage Directive. Customers in France must observe standard NF C 15-100.

 WARNING
Contact with voltage may result in serious injury or death.
Install all equipment and complete all wiring work before turning on the power.

 WARNING
Improper installation can result in incorrect gas level readings or system failure.
Carefully follow all instructions to ensure proper system operation.

Main power supply

Test the current and voltage running through a network before making any connections. Never connect the device without first disconnecting the power supply. The central controller does not have an on/off switch.

Protect the central controller from upstream current with a 4A bipolar differential circuit breaker with a type D response curve. This circuit breaker must be included in the electrical installation of the building and must be placed near of the device and must be available for the operator. On the circuit breaker will be indicated that it is the circuit breaker of the device.

Main power supply 100-240VCA: connector terminals L, N, and PE of the power supply 24V (Fig 3) for wall-mounted version or see connector picture 4 for rack version..


Pre-cabled wires are used to connect to the 24 VDC power supply module. The transformer output connector is also hardwired to link to the 24 VDC central controller connector and to the (optional) integrated printer for the rack-mounted version.

Grounding the central controller

The central controller is intended for use in areas that meet the Class II requirements for overvoltage and degree of pollution as per EN IEC 60947-1. In order to comply with the standard, the internal ground terminal *must* be grounded (Fig 3).

Digital lines

The various digital modules are connected with "Bus" connectors (Fig. 5). Recommended cable: RS-485: 2 shielded twisted pairs, 100 Ω .

One pair is used to power the module, and the other is used for communication. The cable shield or tress should be connected to the terminal: 

i *Data wires and the shield wires should be cut as short as possible.*

Internal relay dry contacts

The RCT dry contacts for the 3 internal relays R1, R2, and R3 are available on the CPS central controller motherboard on connectors J23, J24, and J25 (Fig. 7). Working load: 2 A at 250 VAC, 24 VCC.


Associated alarm type: R1 (alarm/fault), R2 (alarm), R3 (alarm).

RS-485 serial link out

Recommended cable:

RS-485 cable: 1 shielded twisted pair, 100 Ω . (Fig. 6).


MOTHERBOARD FOR RACK-VERSION CPS



Overview of the Motherboard

Part	Connector function
(1)	110-240VCA main power supply (rack version)
(2)	24 VDC external power supply connection
(3)	110-240VCA power supply for (wall-mounted) power supply module
(4)	24 VDC power supply output for power supply module <i>motherboard + integrated printer (rack-version option) power</i>
(5)	Internal contact relay outputs (RTC) <i>dry contacts, potential free</i>

Part	Connector function
(6)	Digital addressable modules <i>8 line connectors for connecting digital modules (CPS 10 – CPSRM – CPSDI16 – CPSAO4)</i>
(7)	RS-485 digital output <i>links to a supervision system</i>
(8)	USB serial interface <i>(PC/COM_CPS connection for configuration)</i>
(9)	RS-232 serial interface link <i>PC/COM_CPS connection for configuration, External serial printer connection</i>
R1, R2, R3: central station shared internal relays	




The wall-mounted version connects directly to the power supply board.

Inspecting the digital buses

Bicolor (red/green) LEDs located above each line start, on the motherboard, allows for inspection of the bus links as follows:

LED appearance	Status
Red + Green LEDs lit (LEDs blink rapidly, almost imperceptibly) Orange in appearance	Normal operation. Red LED → question Green LED ← response
Red LED blinks once per second (green LED is off) Red in appearance	Communication fault. Missing or faulting module.
Irregular blinking	Poor communication quality
Both LEDs off.	No active modules




Mini-switches

Mini switch A allows the CPS controller to download and read the user program. When the switch is in the “MEM” position (open padlock), the user program memory is accessible and the message “switch open” is displayed on screen. The CPS central controller waits to download the program from the *COM_CPS* software. The CPS central controller goes into “shut-down” mode when mini switch A is in the “MEM” position.

When the *COM_CPS* software programming is complete, the mini switch should be flipped back to the “Prog” position (closed padlock), and the central controller should be rebooted to initialize all of the newly loaded settings.

Mini switch B only used for the central controller’s internal microprocessor. It should always be in the “Run” position.



COM_CPS Internal relay and buzzer

The CPS central controller is equipped with **3 internal relays [R1, R2, R3]** and a shared **Buzzer**. The operating settings for the relays and the buzzer can be set with the *COM_CPS* software (see table below).

The internal buzzer is activated when a specific program-defined event occurs (fault or alarm). All lines share relays R1, R2, and R3.

The buzzer’s pitch will vary according to the alarm threshold. Alarms 1 and 2 have the same frequency. Alarms 3 and 4 have a different pitch, allowing the operator to distinguish between alarm levels.

The buzzer can be disconnected by removing the “buzzer activation strap” (J10) located on the motherboard next to the buzzer (cf -: Overview of the Motherboard).

Function / Component	Relay R1	Relay R2	Relay R3	Buzzer
AL 1	X	X	X	X
AL 2	X	X	X	X
AL 3	X	X	X	X
AL 4	X	X	X	X
Module error		X	X	X
System fault*		X	X	X
Out of Range and Fault	X	X	X	X
Positive security		X	X	

*: (System fault) alarm is triggered if there is a communication fault between modules, a short-circuit in a power supply line, or a module inversion.

X: Function can be activated or deactivated

■: Default configuration setting, cannot be changed by user.

USB / RS-232 serial connectors

The CPS central controller is equipped with a serial port which are used to:

- download the user software (see *COM_CPS* instructions);
- program the integrated micro application according to the position of mini switches on the board (factory setting).

i The serial port has 2 interfaces: **USB** and **RS-232**. Only one can be used at a time.

The settings for the central controller can be modified after the program has been created. (Use either the USB or RS-232 adapter to connect the PC to the CPS central controller.

(See Chapter 7 – Program transfer).

USB Interface (1)

Use a USB cable to connect the PC to the CPS central controller running the *COM_CPS* application.

The USB interface emulates a serial port and is preferable to an RS-232 serial connection.

The corresponding USB driver must be installed before the PC is connected to the central measuring station (see *COM_CPS* instructions).

SUB-D 9 RS-232 Interface (2)

Use a cross-over RS-232 serial cable to load the user software.

RS-232 cable series reference number:
6 116 026


A serial printer can be permanently connected.

This would allow you to load the software via the USB interface without disconnecting the printer.

RS-485 serial connection (3)

The RS-485 serial port (3) is reserved for the supervision system and is composed of an RS-485 interface using JBUS/MODBUS protocol.

A table containing all of the important information pertaining to the central controller can be found in the **corresponding annex of Chapter 8**.



Printer (Optional feature)

Connection: Central controller RS-232 interface via an RS-232 serial cable.

Communication settings: 19200 Bd, 8 bit, no parity.

Event printing "on the fly."

Status table printing (choice of four printing schedules). *For example: average readings over 20 minutes, 1 hour, or 8 hours, summary of alarm and relay statuses.*

"Out of paper" functionality: no data is lost when the printer runs out of paper. Once more paper has been loaded, printing will resume where it left off.

Data flow is managed as follows: XON/XOFF Protocol

The printer is ON

The central controller sends data to the printer on start-up. If the printer's power supply fails or if the RS-232 cable is disconnected, data sent from the central controller will be lost.

In the event that the RS-232 cable becomes disconnected, it may be necessary to turn the printer off and on again to reinitiate data transfer.

The printer is OFF

No data is delivered to the printer. The central controller stops sending data when the printer signals the CPS central controller that it is no longer available (Buffer is full, out of paper, or printing stopped with the ON/OFF button).

The central controller will reinitiate data transfer once the printer signals that it is available (empty buffer, or signal through the printer's ON/OFF button or online button).

The front panel circuit

The central controller front panel circuit is equipped with:
















1 LCD display: backlit, 2 lines by 32 characters and a pictogram line for viewing sensor readings and the zone in question, various test point data, settings, events, etc.

3 lights on the front panel of the central controller (green for power, yellow for errors, and red for exceeding thresholds) serve as constant system status indicators.






7 keys to select on-screen information and/or validate certain operations via menus. The menus are available in English, French, German, Spanish and Dutch.




Display Screen

	No alarms or errors
	Icon associated with one or more alarm icons indicates (by blinking) that the associated alarm is an averaged alarm.
	SOLID = instantaneous alarm 1 BLINKING = averaged alarm 1 (takes priority over solid state)
	SOLID = instantaneous alarm 2 BLINKING = averaged alarm 2 (takes priority over solid state)
	SOLID = instantaneous alarm 3 BLINKING = averaged alarm 3 (takes priority over solid state)
	SOLID = instantaneous alarm 4 BLINKING = averaged alarm 4 (takes priority over solid state)
	SOLID = stable signal in hysteresis interval (calculated over 1 minute)
	SOLID = signal increased in relation to the minute before BLINKING = Exceeding the scale (takes priority over solid state)
	SOLID = signal decreased in relation to the minute before BLINKING = Negative fault (takes priority over solid state)
	SOLID = buzzer on
	SOLID = calibration underway
	SOLID = LS (low speed) relay control active
	SOLID = HS (high speed) relay control active
	SOLID = Error
	SOLID = mains power supply OK BLINKING = battery or mains power supply problem

Keys

	Keys primarily used to modify values (ex: line number)
	Keys primarily used to navigate menus or to change variable current (ex: go from line number to sensor number)
	Key used to validate a menu or an input that would alter system operation. (ex: activation of a relay)
	Key used to return to a previous menu screen or to cancel a selected value before it has been validated.
	Key used to acknowledge a locked alarm (programmed for manual acknowledgement) or to dismiss a buzzer relay after its holding time, even if an alarm is still active.

Lights

	<p>Green LED: power supply status indicator SOLID = OK BLINKING = power supply problem (no power to main or problem with the battery pack)</p> <p>Orange LED : indicates the presence of one or more faults.</p> <p>Red LED: signals the presence of one or more alarms.</p>
--	---

Alarm thresholds

Six alarm thresholds can be programmed and adjusted for each sensor:

Alarm 1, Alarm 2, Alarm 3, Alarm 4, Out of Range and Fault.

Alarms 1 – 4 can be:

- **Instantaneous;**
- **delayed** (0 to 3,600 seconds);
- **averaged** (period of 1 to 480 minutes).

This makes it possible to **calculate STEL and TWA values.**

So, for example, you could choose to activate Alarm 1 if the average calculated levels over a period of *8 consecutive hours* exceeded *50 ppm*, and Alarm 2 if average levels over a period of *10 minutes* exceeded *100 ppm*, and Alarm 3 if the *instantaneous reading* exceeded *200 ppm*.

Averaged alarms are only triggered at the end of a complete time interval.

If the line or the detector module stops, average value calculations are halted and will only begin again once the line or the detector module has been reactivated.

Both the instantaneous and averaged alarms can be set to trigger on an increasing value (rising edge) or on a decreasing value (falling edge).

- **Rising edge:** alarm is activated when levels increase. Use this option for sensors measuring Explo, CO, H₂S, etc.
- **Falling edge:** alarm is activated when levels decrease. Use this option for O₂ sensors, for example.

Out of Range alarm: can activate an alarm, a relay, or an LED.

“Verification” option: this option is activated for explosive gases. When a “verification” alarm occurs, the level displayed will be frozen at the maximum value until it is acknowledged (manually or automatically) and on the condition that the gas levels have fallen under the alarm threshold.

Example of ventilator command functionality for CO/NO detection

Alarm threshold	CO (ppm)	NO (ppm)	RESPONSE
Alarm 1	50	25	Ventilators start on low speed
Alarm 2	100	50	Ventilators go to high speed
Alarm 3	150	75	Max speed ventilation + alarm lights in the surveillance area
Alarm 4	200	100	Visual & audible alarms + restricted area access + evacuation orders for individuals in the area

Alarm acknowledgement

Alarms can be rearmed in two ways:



Manual acknowledgement: the audible alarm can only be dismissed after the “Acknowledge” button on the CPS central measuring controller has been pushed; or

Automatic acknowledgement: the audible alarm will be automatically dismissed once the alarm condition has ended.

If an alarm is triggered, a corresponding message will appear on the screen, an audible alarm (BUZZER) is activated, and the red LED on the front panel is illuminated.


Touching the “Acknowledge” button once will remove the message from the screen and will turn off the BUZZER.

Touching the “Acknowledge” button a second time will re-arm the programmed alarms. These alarms will not turn off until the concentration of gas falls below the threshold.

Chapter 4 Digital Modules

View of Digital Modules

SENSOR MODULE CPS 10




PART	DESIGNATION	CO	NO	NO2	EXPLO
A	CPS 10 SENSOR MODULE	6 513 591	6 513 592	6 513 593	6 513 594
1	CPS 10 SENSOR	6 798 301	6 113 331	6 113 332	
2	CPS 10 BOARD	6 451 597	6 451 598	6 451 599	6 451 600
3	SENSOR WASHER	6 136 243	6 136 243	6 136 243	

Part	DESIGNATION
4	Power supply & network connector
5	Configuration switches (Addresses)
6	Calibrator LED
7	Button [sensor replacement]
8	Measurement connector [sensor replacement]
9	Sensitivity adjustment [sensor replacement]
10	Zero adjustment [sensor replacement]
11	6 153 046 CPS 10 Magnetic switch
12	6 136 052 D2 line washer (qty : 0.316)


RELAY MODULES CPSRM4-CPSRM8

Part	DESIGNATION
1	Power supply & network connector
2	Programmable relays (8 or 4)
3	potential free RTC output contact
4	Safety switch + or - relays
5	Configuration switches (Addresses)
6	Logic Input terminals (2 Inputs)




DESIGNATION	CPS RM4	CPS RM8
RELAY MODULE	6 313 962	6 313 963
RELAY MODULE BOARD	6 451 601	6 451 602

LOGIC INPUT MODULE CPS AI16



Part	DESIGNATION
1	Power supply & network connector
2	Logic input terminal (16 Inputs)
3	Configuration switches (Addresses)
4	Module board

ANALOG OUTPUT MODULE CPS AO4



DESIGNATION	CPS AI16	CPS AO4
MODULE	6 313 964	6 313 980
MODULE BOARD	6 451 603	6 451 614


Connecting Digital Modules

General topology of the RS-485 network

Modules are connected in “parallel” in the RS-485 network, comprised of a 1 twisted pair cable for signals, 1 or more pairs to supply power to the modules, and 1 shield wire.

A 120 Ω end of line resistor (**EOL RESISTOR**) should be placed at the last module in the line, at the end of the bus (see Chapter 4 - End of Line Resistor).

The modules are equipped with a double connector, which can be split to easily connect conductors and also allows you to isolate the module while maintaining line continuity.



Wiring the digital network

The sensor module has two cable glands. One connects to the input wire, and the other connects to the output wire which is routed to the next module.

The modules should be wired with RS-485 shielded twisted pair cable, with a normal impedance of 100 Ω, of at least 0.22mm² in diameter. +24VDC, 0V A and B terminals are linked to +24VDC, 0V terminals A and B in other modules in the line, and then linked to the connector corresponding to the central controller. The cable shield should be connected to a ground terminal marked with the following symbol: (Fig.9).




WARNING

An improper installation can cause incorrect gas level readings or system failure.

Do not run cable near equipment such as motors, transformers, or any lines generating a large magnetic field.

Always check to ensure that the cables are completely separated from other circuits.

i Do not leave any stripped wire ends exposed. To guard against electromagnetic disturbances, the data cables and the screen (tress) cables should be cut as short as possible



Configuring the communication settings

Slave address

All modules in a line should be identified with a unique slave number. Switches 1-5 on the **Configuration Switches** unit (Fig. 10) contained in each module, allow you to set a binary numerical address (1...32).

Possible combinations are listed in the address table below.

Notes: The physical address of a module (1...32) should be identical to the address recorded in the central controller configuration program with *COM_CPS*.


When replacing a module, set the configuration switches in the new module to the same position as those of the module being replaced.

i Switches 6 (*FRAME FILLING*) and 7 (*DELAY*) should be in the *OFF* position (*unused options*).

End of line resistor

The last module in each line should be equipped with an end of line resistor.).

i This switch should be in the *OFF* position for all other modules in the line.



Address Table

Slave Address	SWITCHES				
	ON = 1 ; OFF = 0				
	1	2	3	4	5
1	1	0	0	0	0
2	0	1	0	0	0
3	1	1	0	0	0
4	0	0	1	0	0
5	1	0	1	0	0
6	0	1	1	0	0
7	1	1	1	0	0
8	0	0	0	1	0
9	1	0	0	1	0
10	0	1	0	1	0
11	1	1	0	1	0
12	0	0	1	1	0
13	1	0	1	1	0
14	0	1	1	1	0
15	1	1	1	1	0
16	0	0	0	0	1

Slave Address	SWITCHES				
	ON = 1 ; OFF = 0				
	1	2	3	4	5
17	1	0	0	0	1
18	0	1	0	0	1
19	1	1	0	0	1
20	0	0	1	0	1
21	1	0	1	0	1
22	0	1	1	0	1
23	1	1	1	0	1
24	0	0	0	1	1
25	1	0	0	1	1
26	0	1	0	1	1
27	1	1	0	1	1
28	0	0	1	1	1
29	1	0	1	1	1
30	0	1	1	1	1
31	1	1	1	1	1
32	0	0	0	0	0

CPS 10 Detector Module

The CPS central controller accepts 10 types (or 10 different configurations) of sensors. The type of sensor used in the module depends on the gas being monitored. Electrochemical sensors are used to measure CO, NO, NO₂, for example, while catalytic sensors measure gases such as GPL, CH₄, and H₂).

Available Detector Types

Sensor	Measurement	Sensor life expectancy
Carbon monoxide	CO : 0 ... 300 ppm	36 months
Nitric oxide	NO : 0 ... 100 ppm	24 months
Nitrogen dioxide	NO ₂ : 0 ... 30.0 ppm	24 months
Methane	CH ₄ : 0 ... 100 % LEL	48 months
Liquefied petroleum	LPG : 0 ... 100 % LEL	48 months
Hydrogen	H ₂ : 0 ... 100 % LEL	48 months

Sensor module fault

In the event of a sensor module fault, gas levels are no longer taken into account, and all alarms are cancelled, except for the negative threshold (or fault) which is activated. Average values are no longer taken into consideration and the calculation of average values is paused.

If a sensor faults, it can be replaced while the central controller is still running (hot swap) without replacing the detector.

Detector settings

The following settings apply to each type of detector:

- **The abbreviated name to be displayed on the central controller:** NO, CO, CO₂...
- **The name of the gas:** Carbon monoxide, Nitric oxide, Oxygen, Methane ...
- **Unit:** ppm, LEL, %v/v ...
- **Range with display format:** 100, 10.0, 1.00, ...
- **Actionable thresholds:**
 - o 4 instantaneous thresholds: 0-100% measuring range,
 - o 4 averaged thresholds : 0-100% measuring range, (time interval programmable from 1 to 480 minutes).

If the operating time is inferior to the averaging time interval, the averaging time interval is ignored.

An instantaneous threshold is associated with an averaged threshold to generate an alarm. These two thresholds can be set to trigger on the rising edge (increasing alarm) or the falling edge (decreasing alarm).

Alarm delays (0s to 60 min):

Each of the 4 alarm thresholds can be delayed. If gas levels are in excess of an alarm threshold for an amount of time inferior to the programmed delay, the alarm will not activate.

The alarms can be acknowledged automatically once the alarm is turned off, or manually when the gas levels are once again under the threshold.

Fault thresholds:

- o “underscale” negative signal (exceeding the lower threshold): -10% of the range.
- o “SUP” out of range (exceeding the upper threshold): +120% of the range.
- o “Verification” for all explosive gas sensors, in case an LEL threshold is passed, the SUP alarm remains on even after levels fall under the threshold. The fault alarm is also triggered.

Hysteresis:


Max. 1% of range. Default value = 0%.

Example (see opposite page):

Measurement range = 300 ppm; Alarm = 100 ppm;

Hysteresis (1% of range) = 3 ppm

Level at which alarm can be dismissed = 97



External relay module

The relay module is available in two versions: CPS RM4 (with 4 relays) and CPS RM8 (with 8 relays). It also has two logic inputs (LI) which can be activated.

In maximum configuration, the CPS can manage 256 relays (ex: 32 modules with 8 relays each). For more information about the logic inputs: see: Logic inputs module.

The relays are individually programmable. The operation of each relay depends on its configuration and its function.


Each of the 6 sensor alarms [AL1 - AL2 - AL3 - AL4 - Out of Range - Fault] can control one or more of the 256 relays. Several events can be linked to one relay.

In case of a module relay fault, all relays of this module are restarted.

The CPS central controller will change the relay status unless they belong to a different module type. Restarting will resolve the problem.

Relay status lights


Each relay has a red LED to indicate its status	
Red LED appearance	Status
DEL lit	Activated relay (alarm condition exists)
DEL off	Non-activated relay (no alarm condition)



“Positive/negative” relay security

In addition to switches of CONFIGURATION, RELAY MODULES INCLUDE SWITCHES OF POSITIVE AND NEGATIVE SECURITY CONFIGURATION. Flip the switch to **ON (positive security)** or **OFF (negative security)** as desired. Each switch acts on its corresponding relay (switch 1 → relay RL1, switch 2 → relay RL2, etc.). (Fig. 11).

Note: Only switches 1-4 are active in the CPSRM4 module.



“Normal” relays

The relay is activated when an alarm occurs and is deactivated when the alarm condition ends.

The variables acting on a relay in alarm status are:

- Alarm delay
- Automatic / Manual acknowledgement
- Forced state change via the CPS menu
- Forced state change via a logic input command

“Buzzer” relays

The “Buzzer” relay is used to control an audible alarm.

It can be re-armed with the [**Acknowledge**] key on the central controller, even if the alarm condition has not changed.

The occurrence of a new alarm will reactivate the relay and reset the delays.

The “Buzzer” relay can be automatically dismissed before the end of the alarm with a 15 to 900 second delay (standard setting for “Buzzer” relays) or manually, even if the alarm condition has not changed. It can be configured with a minimum operating time of 1 sec. to 5 min.

The variables acting on a relay after an alarm has occurred are:

- Alarm delay
- Automatic / Manual acknowledgement
- Forced state change via the CPS menu
- Forced state change via a logic input command

Alarm and/or “Buzzer” relay delays

Alarm delays		Relay delays
Instantaneous Alarms	Averaged Alarms	“Buzzer modes”
1 ... 3600 seconds	1 ... 480 minutes	Min. activation time: 0 ... 300 seconds
		Acknowledgement time: 15 ... 900 seconds
Standard settings for each sensor type		Standard settings for all “Buzzer relays”

“LS/HS” Relays

Low speed (**LS**) relays and high speed (**HS**) relays are always used together, allowing you to control a parking facility ventilation system at two speeds.

LS (low speed) : The relays are designed to control slow ventilator speed (star-triangle configuration for a two-speed ventilator).

HS (high speed) : The relays are designed to control high speed ventilator speed (star-triangle configuration for a two-speed ventilator).


The working logic of the relays defined hereafter, takes into consideration the start-up and shut-down intervals during which very high levels of current may occur, capable of damaging motor windings if phases occur in the incorrect sequence.

“LS / HS” Operation

Requirements: Alarm level 1 < Alarm level 2

The LS relay is activated by Alarm 1

The HS relay is activated by Alarm 2



Phases		Action operation	Default Delay*
T₁	Min. duration LS operation Adjustment(s): [1 ... 32767]	Minimum duration, in seconds, during which the ventilator operates at low speed	5 min.
T₂	HS operation delay Adjustment(s): [2 ... 32767]	Minimum duration for Alarm 2, after which the ventilator switches to high speed	15 min.
T_{R1} R₂	LS/HS transition time 1 second (cannot be changed)	Transition time between Relay 1 and Relay 2 is 1 second (standardized throughout the central controller)	1 sec.
T₃	Min. duration HS operation Adjustment(s): [1 ... 32767]	Minimum duration, in seconds, for the ventilator to operate at high speed. HS relay deactivated if Alarm 1 condition ends	10 min.
T₄	LS-HS stop delay Adjustment(s): [1 ... 32767]	Duration, in seconds, after low or high speed ventilator operation has been stopped, before the ventilator can be restarted at low speed.	10 min.

Time values **T₁**, **T₂**, **T₃** and **T₄** can be modified. When the “**Sensor simulation**” menu is used (see the chapter on the maintenance menu/simulation on page 43) the times are decreased, by default, to 12 seconds, 24 seconds, 36 seconds, and 24 seconds, respectively.

Note: An underscale alarm (= fault) activating a LS or HS relay will force the relay into HS position (with respect to the defined time).

“Forced ventilation” function

This is a forced relay state change via the CPS menu. This function allows you to block or release the HS (high speed) command at specified times.

Forced relay state change via a logic input command

In both cases the response is immediate and priority safety settings are maintained: HS takes precedence over LS, and both relays are shut-down if there are contradicting signals.

Logic Input Module

COM_CPS

This module contains 16 logic inputs, linking priority commands, such as fire extinguishers directly to the central controller.

A maximum of 224 total logic inputs across all modules can be activated.

Example 1: 112 modules having 8 relays each, with activated inputs.

Example 2: 7 modules with 16 logic inputs with activated inputs.

Each input can override all other commands to activate or block up to 256 relays.


Priority inputs

Two levels of input priority can be managed on each module with the *COM_CPS* software.

Priority inputs have control of the other inputs (all of the non-priority inputs are “blocked” when a priority input is activated).

In the event that two different inputs of the same priority level send contradicting orders, the relay is shut-down.

In the event of a fault, the inputs are set to zero.



COM_CPS

Analog Outputs Module

This module is comprised of 4 opto-isolated 4-20 mA analog outputs which can be individually activated or deactivated.

Activated: the output analog signal (4-20 mA) varies, according to the input

Deactivated: the analog output signal will be frozen at 0mA, regardless of the input signal.

Several events can be linked to one output. In this case, the largest analog value will be recopied onto the analog output.


The output module also has two logic inputs (LI), identical to those on the “Logic input” module.

A “slave address” for the module can be set with the “DIP” switch (DIP1).

An analog output OFF command from the central controller corresponds to 4 mA.


An analog output ON command from the central controller corresponds to 20 mA.

Connections:
**Analog
output
module**



Chapter 5 Detailed Menus

Menu Tree



Start-up Phase

No faults or alarms are processed during the first minute after start-up. During this phase, the central controller runs a Checksum test (1), a RAM test (2), a line start-up (3) and a module mapping test with a program stored in its memory.

Voltage builds progressively in the lines. Progress bars show the overall progress for line power-up.

Only the power-up of activated lines is shown (identified by a diamond "◊" during the initial power-up phase, and by a black square "■" at the end.)

An exclamation point "!" indicates a short-circuit line fault. The line can be reactivated through the menu system.

Next, a sensor stabilization phase occurs (4) during which time, the alarms are deactivated.

An inspection phase immediately follows in order to verify that the configuration program set with the **COM_CPS** software correctly maps to the modules installed and activated.

If no errors are found, the program runs normally. If errors are detected, the modules in question will be flagged as faulting.









After the start-up phase, the screen will display information pertaining to the selected mode: **events (a)** or **cyclic (b)**. The central controller begins to process data coming in from the various modules.

In cyclic display mode, when no alarms are triggered the levels from each sensor are displayed on the first line of the display screen.

In case of a power outage, the program configuration will be saved. When the controller is turned on, the last program installed by **COM_CPS** will be loaded.

If a sensor faults, the message "Def" will replace the reading value. If the power supply is interrupted within a line, the two points in front of that line will blink. Identify the problem by touching the [ESC] key to display the error message.

If the gas level exceeds a high or low threshold, "Ovs" will appear on the display screen where the value for that sensor would normally appear. This message will display simultaneously with a blinking arrow (pointing up or down, depending on the situation).



Control Menu

Normal Display

Alarm pictograms will appear and disappear in along with the alarm conditions detected by a given sensor. The display shows gas level readings, which may not always be identical to the status of a relay. Under normal conditions, alarm pictograms reflect relay status.

Example: LS and HS relays are configured to run on a delayed trigger. Pictograms do not take this delay interval into consideration. So it is possible that the LS or HS relay is on, while the alarm pictogram does not display on screen, due to the alarm delay.

Cyclical display

This menu allows you to view all of the activated sensors on screen, at a display rate of one sensor every two seconds.

Event display

This menu allows you to view the status of all sensors in alarm mode, faulting, or in calibration, at a rate of one sensor every two seconds.

Sensor Display

This menu allows you to freeze the display on a specific sensor by selecting the line and the module number (The program automatically selects active sensor modules).

Touching the [**OK**] key once will bring up the sensor name, the abbreviated gas name, the gas level and unit of measure (ppm, % LEL, \$v/v).

If the sensor is faulting, "Def" will display in place of the level reading.

Select the line or the sensor (if applicable) using the [**◀**] [**▶**] (horizontal) keys.

Select the line number or the sensor number (if applicable) using the [**▲**] [**▼**] (vertical) keys.

Press [OK] to select the sensor.

Press [OK] a second time to display both the gas reading level and the 4 averaged readings if average readings were activated. If averaging was not activated, < ******* > will display on screen.

If a communication fault occurs, the value will be replaced by < ******* > and the averages will stop on the last calculated value.


For all other faults, the gas level will be displayed in order to help the user identify the problem.



Control 13:18:19




Control Scan & Display




Affichage normal Display on events




Scan & display Cyclic display




Control Sensor Display




Line : 2 Sensor : 1
CPS 10 CO zone 45




L2, Mod : 1 = 0 ppm CO
CPS 10 CO zone 45



L2 C 1	Avrg .1:	***	2:	***
0 ppm	3:	0	4:	***



L2 C 1	Avrg.	1:	***	2:	***
*** ppm	3:	0	4:	***	



L2 C 1	Avrg.	1:	***	2:	***
-37 ppm	3:	-1	2 4:	***	

Events

This menu can be used to search through a history of the most recent 1,200 events. A record of these events can be printed. State changes are recorded in the history.

If Alarm 1 ends and Alarm 2 is triggered, AL2 ON will be recorded.

Examples:

- (a) The shut-down of a line causes the shut-down of alarms and relays for that line.
- (b) The "fault" alarm is triggered for module 3, line 1.

Other examples:

Module 2, line 8 turned on

30/06/06 (day/month/year) 14:40:36 L:8, Mod:02
Module ON

Alarm 2 triggered

30/06/06 14:49:37 L:8, Mod:02
Alarm 2, OFF ⇒ ON

State change for Relay 2 (command relay)

30/06/06 14:49:37 L:8, Mod:29

Relay 2 Normal ON

Conditions for Alarm 2 end
30/06/06 14:51:03 L:8, Mod:02
Alarm 2, ON ⇒ OFF

Acknowledgement action



30/06/06 14:55:21

ACKNOWLED

State change for Relay 2 (relay shut-down)

30/06/06 14:55:21


Relay 2 Normal OFF




Relay Status

This menu displays the status of a relay in a given module. Increments for the preceding and following modules in the line are automatically calculated.

Display the status for the selected relay by pressing the [OK] button. This screen will show the module, its mode of operation (Normal, Buzzer, LS, HS,...) and its status (ON, OFF).



- (a): (LS / HS) - Delays
- (a): (Buzzer Relay) – Acknowledgement time
- (b): (Buzzer Relay) – Min. activation




4-20 mA Output Status

This menu displays the outputs for the selected module. The value is displayed in mA.

Multiple inputs can be linked to one output. In this case, the largest analog value will be recopied onto the analog output.

Activated analog output: the 4-20 mA output signal varies according to the input.

Deactivated analog output: the 4-20 mA output signal will be frozen at 0mA, regardless of the input signal. The output current for each channel will vary between 0 and 24.5 mA.



Printing

“System status” Report

This menu is used to initiate the printing of system status reports. The second part indicates the fault status for all of the modules in each line. Each hexadecimal number corresponds to a module, with Module 1 being on the left, and Module 32 on the right.



0 = OK
1 = Communication error
2 = Module recognition error
4 = Fault triggered by a module fault word.
X = (no programmed module)



If the system detects an abnormality in either the name or the range of a gas, the letter N will blink on the screen

“Status for all line modules” Report

Sensor module: the printed reports will contain both the reading and the averages if averages are activated.

Relay module: the printed reports will contain the status of each relay and of each relay's logic inputs.

Logic inputs module: the printed reports will contain the status of all logic inputs.

“Module status” Report

Prints the status of every module in the selected line. See previous paragraph.

“Printer On/Off” Report

Use the [▲] and [▼] keys to activate or deactivate the printer.

When the printer is activated, the **COM_CPS** cannot be used to for reading or configuration. The configuration mini-switch (A) must be placed in the open padlock position to enable communication between the serial port and the **COM_CPS** software (cf “Programming mini-switches”).

“Event” Report

This feature allows you to print all of the most recent events stored in memory (up to 1,200).

Calibration Report: The calibration data for a sensor is only printed at the end of the calibration process. The record will consist of a title, the line number and module number and 6 readings if a complete calibration has take place:

```
Calibration1
Sensor 4 01 CO
Xo1 = 00004      Zero value before starting procedure
Xo2 = 00000      Zero value
Xo3 = 00000      Zero value after procedure
Xf1 = 00095      Value of the concentration of calibration gas
Xf2 = 00100      Value of the response to the gas
Xf3 = 00100      Value of the reading at the end of the procedure
```

Access code

An access code is required to access certain menus. The access code is made up of 4 hexadecimal numbers. If the wrong code is entered three consecutive times, the code will be deactivated until all menus have been exited or until after 10 minutes of inactivity. The **COM_CPS** software can be used to modify the access code.

The default access code is: **1 0 0 0**

System Menu

Line, Module, Relay Action

Enter the access code by using the [^] [v] and [<] [>] keys.

Line activation

The selected line is displayed along with its number and name.

To go to a different line, use the [^] [v]. Change the status by pressing the [OK] key, and then pressing the [<] [>] keys, followed by [OK].

If the line is shut-down, the line number will flash intermittently with a cross sign. If the module does not correspond with the CPS central controller COM_CPS-created program, its status is reported as faulting.

Notes: *If the line is shut down by the COM_CPS software, it is impossible to turn it on.*

A line is fully activated approximately 5 seconds after start-up.

A thermal fuse protects the line's power supply from short-circuits. Should a short-circuit occur, a fault word will appear in the menu and an error message will be recorded in the event log. After the short-circuit, the line must be reactivated via the menu.

Relay activation

Use the same "Relay Status" menu to select a relay. After pressing [OK] to select the relay, you have three options:

- < Normal > = Relay functions normally (triggered by alarms)
- < ON > = Relay in forced operation (can only be shut-down by a logic input)
- < ON > = Relay in forced shut-down (can only be turned on by a logic input)







Special case: LS and HS relays

For safety reasons, deactivating a LS or HS relay via the CPS central controller shuts down of the two relays and restarts their timing devices.

If a logic input or a command from the CPS central controller activates a LS or HS relay, the relay will be activated. The relay's activation time is set to the maximum value. In other words, the forced relay shut down ends when logic inputs no longer command the relay or after the end of an alarm condition which could control the relay.

Similarly, if an alarm triggers a HS relay, a LS relay cannot be activated.


The forced activation of a HS relay takes priority over scheduled HS freezes.



Activating analog outputs

Choose the 4-20 mA output for the selected module. Pressing [OK] will force a start-up or shut-down for the 4-20 mA output.


- The shut-down freezes the output at 4 mA.
- The start-up freezes the output at 20 mA.


 Output 4 – 20 mA ◀▶


Date and Time


△ Changing the time settings will reinitialize LS and HS delays!


Example: *If the HS relay is activated and the time is changed, the HS relay will stop so that the LS relay can operate according to the predetermined delays.*

 System
Date and hour ◀▶

 Date? ◀▶

 Date (DD: MM: YY)

 Hour? ◀▶

 Hour:
0 9: 3 6


0 3/ 0 7/ 0 7


Start-up Configuration

This menu is used to select which menu will display by default upon start-up and after 10 minutes of keyboard inactivity.

The two menu options are:
Cyclical Display and Event Display.

 System
Start Config ◀▶

 Start Config
Cyclic Display ? ◀▶

 Start Config
Display on events? ◀▶

Maintenance Menu

Simulation

This menu is used to simulate the alarms for a particular sensor module or to temporarily activate one or more relays (or outputs). After exiting the simulation menu, the sensors and relays (excluding LS and HS relays) revert to their prior state.

Enter the access code by using the [^] [v] and [<] [>] keys.

Sensor simulation

Select the sensor module you wish to test. Next, select the delay between each of the alarms to be activated (1-59 sec.). Validate your selections by pressing [OK].

The central controller will increase reading levels until they exceed the thresholds for all activated alarms in ascending order +/- hysteresis. During the simulation, the theoretical values are displayed on screen.

During this phase, the other sensors are shut down. However, forced-state lines, modules and relays remain active.

Relay Status Simulation

Select the relay module for the relay you wish to test, then the relay you wish to activate.

Use the same "Relay Status" menu to select a relay. After pressing [OK] to select the relay, you have three options:

- < Normal > = Relay functions normally (triggered by alarms)
- < ON > = Relay in forced operation (can only be shut down by a logic input)
- < OFF > = Relay in forced shut-down (can only be shut down by a logic input)

After exiting this menu, the relay will revert to its original state.

Analog Output Simulation

☺	Maintenance	◀▶
		09: 52: 15

☺	Maintenance Simulation	◀▶
---	---------------------------	----

☺	0000 access
---	-------------

☺	Simulation ! Stop all sensors !	◀▶
---	------------------------------------	----

☺	Simulation One sensor
---	--------------------------

☺	Sensor display Line : 1 Detector : 1
---	--

☺	➔	Step alarm during 10 sec.	0
---	---	---------------------------	---

☺	Simulation Relay status	◀▶
---	----------------------------	----

☺	Line : 2 Module: 1
---	-----------------------

☺	Relay Nr 1 : OFF	0
	2-1-1 LS	0

Module Verification

Inspection of all of the parameters relating to a module with a *communication fault*.

☺ Maintenance
Module Control ◀▶

☺ Line : 2 Module: 1 ON
CPS 10 CO niveau-1

E = Status word
D = Fault word
C = Start-up config. word
M = Level for sensor modules or State for logic inputs
T = Temperature
Cal (Value) = Concentration of gas used for calibration
ID = Module fault

☺ →
1 E 8000 D 0000 C 0003 iD 0000
01 M 0 T 33°C Cal 300

Displays useful variables and operating time according to the module type:
(Value) = line voltage
R = Relay status (hexadecimal)
(Value) J = Number of days since last calibration.
0 = X0 for sensor modules.
f = Xf for sensor modules.
U = Wear rate for sensor modules.
CRC = (*Cyclic Redundancy Check*)
Software version for the module program.

☺ →
1 01 23.10V CRC=EAA5 1J
0= 0.00% f=100.00% U= 0.00%

☺ →
2 01 22.37V CRC=404C
R=00

Dep. (value) H = Time (in hours) during which the sensor exceeded the scale.
Ref: (Value) = Sensor reference.

☺ →
1 01 Dep. 0.0 H
Ref=6514000 6001 001 1.0 Ty0

Retry: (plural form, *retries*) – attempt(s) at retransmission. Used to control the quality of communication with the modules.
(a): represents successful transmission attempts. This number increases continually and should be as large as possible.

☺ →
1 5813939 (a) 4 (b)
01 3 (c) 0 (d)

(b), (c), (d): represents next 3 successive retransmission attempts, if necessary, following a failed attempt. In the event that the 1st attempt (1) fails, a 2nd attempt (b) will occur, then a 3rd (c), and 4th (d). The number and the level of saved attempts is indicative of the transmission quality. A large number, on level 3 or 4 is due to poor transmission.

☺ →
Reset retry
0000 acces


Reinitialize “retries” by selecting the “Reset retry” menu.

☺ →
Reset retry
Module 1-01 Line 1 CPS

☺ →
1 0 0
01 0 0

Any module fault generates an event, which is identified by a number (hexadecimal coding) corresponding to the fault type. The number at the end of the second line displays the module error.

The [◀] [▶] keys can be used to change the scroll mode: in normal mode, all events saved to memory are displayed; in default mode, only the faults saved to memory are displayed.



Fault word

4	3	2	1
1 = Def Flash	1 = Def Temp. Min	1 = Def Zero calibration	1 = Def ROM main memory
2 = Def sensor	2 = Def Temp. Max	2 = Def Sens. calibration	2 = Def RAM
4 = Low line power	4 = Def Meas. Min	4 = Def Zero Sensor replacement	4 = Def Battery
8 = high line power	8 = Def Meas. Max	8 = Def Sensitivity. Sensor replacement	8 = module parameter does not correspond to the module card

Sample fault word: **00A0** = Def Sens. calibration + Déf Sensitivity. Sensor replacement (A = 10 in hexadecimal = 8 + 2)

Status word

4	3	2 *	1
1 = BitEtatLiss	1 = BitEtatChg	1 = BitEtat0	1 = BitMod0
2 = BitJbFill	2 = BitEtatPar	2 = BitEtat1	2 = BitMod1
4 = BitJbDelay	4 = BitJbWait	4 = BitEtat2	4 = BitMod2
8 = BitEtatCell **	8 = BitJbCar	8 = BitEtat3	8 = BitMod3

** : only for sensor module (indicates presence of a sensor)

2 *	Status
0 (EtatMes)	Normal measure
BitEtat0 (EtatStab)	Stabilization
BitEtat1 (EtatZInit)	Zero init
BitEtat0 + BitEtat1 (EtatStab)	Zero Stabilization
BitEtat2 (EtatZVal)	Zero validation
BitEtat0 + BitEtat2 (EtatSWait)	Sensitivity waiting
BitEtat1 + BitEtat2 (EtatSInit)	Sensitivity init
BitEtat0 + BitEtat1 + BitEtat3 (EtatSStab)	Sensitivity stabilization
BitEtat3 (EtatSVal)	Sensitivity validation
BitEtat0 + BitEtat3 (EtatChg)	Button replace pushed

Module Designation		Type
1	Sensor CO	0
2	sensorNO	1
3	Sensor NO ₂	2
4	Sensor EXPLO	3
5	Sensor O ₂	4
6	Free	5
7	Free	6
8	Other	7
9	4 relay mod	8
10	8 relay module	9
11	Free	A
12	Free	B
13	4ana output mod	C
14	16 log input mod	D
15	Analog input mod	E
16	Free	F

Chapter 6 Maintenance

Program transfer

This chapter describes the transfer of data from the *COM_CPS* application to the CPS, and vice versa (see the *COM_CPS* user's guide). After launching the software, you will see a welcome window.

PC → CPS transfer

Once the program has been created, the central controller should receive new settings..

Step 1: establish a physical connection

- 1) Use either the USB or RS-232 adapter to connect the PC to the CPS central measuring controller.
- 2) Ensure that the CPS central measuring controller is connected to a power source.
- 3) **On the central controller:** flip the programming switch to the "MEM" position. The message "Switch open – Program..." will appear on the display screen. Communication with the central controller is authorized during this phase..

Step 2: link configuration

- 1) In the menu bar, select [Communication > Port].
- 2) Select the port [COM x] to use on the PC.

Note: communication speed is selected automatically.

Step 3: data transfer

- 1) In the menu bar, select [Transfer > from PC to CPS]. The message "Flip switch to MEM position in order to reprogram the central controller" refers to the <MEM> position on the CPS central controller commutator before starting the transfer procedure. Click [OK] once verification has ended.
- 2) During the transfer, a progress bar will indicate transfer progress.
- 3) Once the transfer is complete, the message "Operation complete" will appear on screen. Click [OK]. The configuration program has been transferred from the PC to the CPS central controller.
- 4) **On the central controller:** The message "Switch open – Complete" will appear on the display screen. Flip the programming switch to the "Prog" position.
- 5) The central controller will perform a "Start-up" procedure.

CPS → PC transfer

Step 1: establish a connection

- 1) Use either the USB or RS-232 adapter to connect the PC to the CPS central controller.
- 2) Ensure that the CPS central measuring controller is connected to a power source.
- 4) **On the central controller:** flip the programming switch to the "MEM" position. The message "Switch open – Program..." will appear on the display screen. Communication with the central controller is authorized during this phase.
Or, use the "Control" menu to set the printer to "OFF."

Step 2: link configuration

- 1) In the menu bar, select [Communication > Port].
- 2) Select the port [COM x] to use on the PC.

Note: communication speed is selected automatically.

Step 3: data transfer

- 1) In the menu bar, select [Transfer > from CPS to PC].
- 2) The message, "Do you want to read the CPS central controller configuration?" will appear onscreen. Click [OK]. If the message, "Check port configuration and ensure printer set to OFF position and try again" appears, verify that the CPS printer is in the OFF position.
- 3) Select the folder where you want to download the file, and create a file name (a default name is suggested).
- 4) During the transfer, a progress bar will indicate transfer progress.
- 5) Once the transfer is complete, the message "Operation complete" will appear on screen. Click [OK]. The data has been transferred from the CPS central controller to the PC.
- 6) **On the central controller:** The message "Switch open – Complete" will appear on the display screen. Flip the programming switch to the "Prog" position.
- 7) The central controller will perform a "Start-up" procedure.

Error messages

Error messages will appear in the following scenarios:

ERR 01: Module fault relating to the program.

The test runs systematically on start-up and periodically when a module is activated by the menu if the module does not correspond to the loaded program. The error remains until the problem is corrected or until the module is shut down.

ERR 02: Fault word reading for a module. Name displayed on the 1st line of the screen.

ERR 04: Power line error.

ERR 08: I2C (real-time clock) or EEPROM error.

ERR 10: Module communication error.

ERR 20: Problem originating at printer. Printer shut-down or lack of paper.






Checksum error

When the central controller starts up, checksum values appear briefly on screen after the display test. The value calculated by the central controller is displayed on the first line, and the checksum calculated by the PC with the *COM_CPS* software is displayed on the 2nd line.

If these two values are different, this screen will remain on the display screen, indicating that there is a problem (example: depleted battery.) The user program protection switch must be flipped, and a new *COM_CPS* program must be transferred.

Flip the switch back into the “closed padlock” position before restarting the central controller.

Example of an error

<p>Operation before event</p>	 <p>CPS Analysis 21:04 Parking Charles de Gaulle</p>
<p>Technical alarm triggered (fault). buzzer engaged (if activated), Front panel yellow LED illuminated. Two pictograms appear: the blinking “maintenance key” and the “siren.”</p>	 <p>CPS Analysis 21:04 Parking Charles de Gaulle</p>
<p>Action on the front panel “acknow!” button. Audible alarm (buzzer) is off. “Siren” pictogram disappears. “Maintenance key” pictogram remains on screen. Front panel yellow LED illuminated.</p>	 <p>CPS Analysis 21:07 Parking Charles de Gaulle</p>
<p>Action on the “acknow!” button. Direct access to the “ERRORS” data page. ERR 11 = ERR 10 + ERR 1 Communication fault for Module 1, Line 2. Check the line and/or the module. The fault will disappear when the problem is resolved.</p>	 <p>Relay module level-1 ERR11 : Com. 2 01</p>
<p>If multiple errors occur, all of the error codes will be displayed one after another. The faulting modules for each error will be displayed one at a time by their line number and module number.</p>	 <p>Sensor CO 1, level-1 ERR01 : Type 2 01 Meas=x.x</p>

Testing and calibration of stable installations

Warning : The setting of this section are reserved for authorized persons formed because they might call into question the reliability of detection.

The site responsible is required to establish security procedures on its site. OLDHAM may be not responsible for their implementation.

Gas detectors are above all safety instruments. In consideration of this, **OLDHAM** recommends regular planned testing of fixed gas detection installations.

A functional test involves injecting a sufficient concentration of gas at the sensor level to trigger pre-set alarms. This test does not replace a full sensor calibration under any circumstances.

The frequency of gas tests depends on the industrial application in which the detector is in use. Frequent inspections should be made in the months following the commissioning of the installation, and then become more widely spaced provided that no significant deviation is observed.

If a detector should fail to react when in contact with the gas, calibration is essential. The frequency of calibrations is a function of the results of the tests (humidity, temperature, dust, etc.). However, it must not exceed one year. It is also advisable to calibrate the sensor after exposure to high concentrations of gas.

Gas concentration which must be used during manual or semi automatic calibration

- CPS 10 **CH4** = 2.5% CH4/air
- CPS 10 **H2** = 2% H2/air
- CPS 10 **C4H10** = 0.9% C4H10/air
- CPS 10 **CO** = 100ppm
- CPS 10 **NO** = 50ppm
- CPS 10 **NO₂** = 10ppm


Sensor replacement

Sensors should be replaced as a part of regular preventative maintenance or following a failed calibration test.


After replacing a sensor, a calibration test must be conducted (see the chapter on semi-automatic calibration).

To replace a sensor:

- Remove the sensor cover.
- Hold down the sensor replacement button (1) for **5 seconds**, until the solid green LED (2) is on.
- Release the button.
- Replace the sensor and conduct a calibration test (mandatory) according to the semi-automatic procedure.



On the central controller, the “maintenance key” pictogram indicates that the sensor has been replaced. The key will remain on screen until the sensor has been calibrated or until the sensor’s power supply fails. The wear settings for the sensor are initialized upon calibration




Semi-automatic calibration

During a sensor module calibration, the central controller blocks the alarms from the module in question and displays a maintenance key on the screen. Up to 10 sensors can be calibrated at the same time. The concentration level for the calibration gas is stored in the sensor's memory.

Each calibration start and stop is logged as an event.

The printer records a state after the calibration of each sensor (cf : Printing).

If the calibration is failed, the sensor is listed as faulting and an event is logged with a fault code (0010 – calibration zero fault, 0020 = calibration sensitivity fault) .



Manual calibration

The calibration kit provided by ISC must be used (Ref. 6 116 291) female connector / wires / voltmeter connection files).

- Remove the sensor cover.
- Connect the cable (strand) to the circuit's male connector.

Zero adjustment

Ensure that the sensor is in clean air. If not, inject air into the sensor at a flow rate of 60 l/h, then wait for voltmeter levels to stabilize (use the gas injection device: bottle of synthetic air, calibration pipe, tube).

- Adjust the zero with the potentiometer's "ZERO" until the voltmeter reads **0 mV**.




Sensitivity adjustments

- Now inject the known gas (60 l/h) into the sensor, and wait for the voltmeter signal to stabilize.
- Adjust the sensitivity if necessary with the potentiometer "SENS" until the signal value (in mV) corresponds to the amount of reference gas used. **Use the following formula to calculate the correct value for the signal.**
- Stop injecting gas (remove the calibration pipe from the sensor).
- Wait for the voltmeter to "return to zero."

Version CPS 10 for explosive gas

The CPS central controller has a "verification" function: if the sensor measures a concentration of gas higher than 100% LEL, the signal will be dismissed by disconnecting its power supply.

$$U_{(mV)} = \frac{1600 \times \text{Reference gas value}}{\text{Measuring scale}}$$




MAINTENANCE WIRES:

+VCC (red) = + power supply


Signal S (yellow) = signal from 0 mV to 1600 mV for zero and sensitivity measure

Ref 2,5V (brown) = zero reference for signal reading from 0 mV to 1600 mV


GND (black) = electronic circuit ground.



Semi-automatic calibration device




Magnet position.
Respect the magnet position in order to place the magnet horizontally



Semi-automatic calibration

The magnetic calibration allows for one-man and non-intrusive calibration to **save considerable time**.


Manual calibration with zero and span potentiometers is possible by opening the CPS 10



Calibration element

Rep	Part number	Nr	Description
1	6 128 972	1	SUPPORT
2	6 155 771	1	MAGNET MEDER CPS 10
3	6 325 161	1	HANDLE
4	6 331 141	1	CALIBRATION CAP
5	6 902 406	3	SCREW PCL TZ M3*10
6	6 903 305	1	SWIVEL H M3

Slug the gas with a 60L/H discharge



Central controller maintenance

Do not use alcohol- or ammonia-based liquids to clean the central controller. If necessary, clean the exterior of the central controller with a damp cloth.

Lithium battery


If the central controller configuration settings are lost, the lithium battery soldered to the display card must be replaced. This operation should be performed by a qualified professional.

Lithium battery characteristics: VARTA CR1/3N or equivalent.

Back-up battery pack


When the back-up battery power drops, the battery should be replaced. This operation should only be performed by a qualified professional.

The battery pack is located underneath the display screen on the wall-mounted version. Take off the display screen to access the battery pack. Unplug the connector linking the battery pack to the motherboard. Remove the 4 mounting screws. Attach the new battery pack. Plug in the connectors before reassembling the display.



Scrapping of CPS System

Concerning the conservation, of the protection and the improvement of the quality of the environment, as well as for the protection of the health of the persons and the careful and rational use of natural resources, CPS system has to be the object of a selective collection for the electronic equipments and cannot be scrapped with the normal domestic waste. The user thus has the obligation to separate the CPS system of the other waste so as to guarantee that it is recycled in a sure way at the environmental level. For more details of the existing sites of collection, contact the local administration or the distributor of this product.




Chapter 7 Technical Specifications

CPS Central Controller	
CPS w/ metal wall-mounted casing:	Dimensions (mm): 320 x 180 x 95 Degree of protection: IP 54
Cable entries	5 M20 cable glands Diameter 5-12 mm power / local relays. - 9 PG9 1 D-SUB 9 Pin RS-232 cable
CPS rack version	Dimensions: Length: 19" ; Height: 4 U (176 mm) IP class: IP 31
Operating conditions	Ambient temperature: -10°C to 40°C Storage temperature: -20°C to 85°C Humidity: 5 to 95% noncondensing
Power supply	Mains power supply: Voltage: 110-240VCA Battery back-up: Optional – Capacity: 600 mAh 24 V Consumption: 140 mA + 12 mA per measurement line (240 mA max.)
Measuring lines	Number: 8 RS-485 digital measuring lines Line capacity: 32 digital CPS modules (CPS 10, CPS RM, CPS DI16, CPS AO4) ModBus Protocol Cable type: 2 twisted pairs shielded RS-485 4Xawg22 (diameter 0.67mm) cable, 100m Transmission speed: 9600 Bauds (trial with 0.35 mm ²) Module power supply: 12 to 30 VCC via the CPS central controller and if necessary via a 24VCC external additional power supply Digital module network: RS-485 ModBus, addresses 1 to 32, set with mini switches Isolation: Power supply / Digital network: 1500 V
Display	Backlit LCD display [2 lines, 32 characters per line - 1 line for pictograms - 3 electroluminescence diodes to indicate operating status: OK, Fault, Alarms]
Keyboard	Membrane keyboard, 7 intuitive keys
Local buzzer	Alarm and fault signaling
Integrated printer	Optional for rack version (no integrated printer option for the metallic wall casing)
Alarms	Number of alarms: 6 alarms per sensor (AL1, AL2, AL3, AL4, Out of Range, Fault + Validation for Explo gas) Programmable thresholds: For instantaneous or averaged values, increasing or decreasing values, or for manual or automatic rearming.
3 Internal local relays	Relay: R1 (alarm/fault) – R2 (alarm) – R3 (alarm). Minimum charge for RCT contacts: 2A / 250 VAC – 30 Vcc (resistive charge) Relays settings are configured with the COM_CPS configuration software. Torque : 0.5-0.6 Nm
Centralized supervision system digital output connections.	RS-485 ModBus Protocol (connection with a centralized supervision device) RS-232 or USB USB protocol priority (permanent connection to system configuration)
Approvals:	Low Voltage Directive: This device is in compliance with the security requirements of Directive 73/23/EEC, modified by Directive 93/68/EEC, based on standard 61010-1 and its second amendment. Metrology: Underground parking facilities: according to VDI 2053 EMC Electromagnetic compatibility: according to EN 50270


CPS 10 Sensor Module	
Dimensions (mm):	118 x 110 x 60
Degree of protection:	IP 65
Cable entries:	2 M16 cable glands 4-8 mm diameter
Consumption:	Toxic gas sensor: 2.5 mA in normal operation Explo gas sensor: 50 mA in normal operation
Status indication after calibration	Red/Green electroluminescent diode
Calibration:	Automatic, no need to open the sensor due to a gas introduction device equipped with a magnetic switch, or with a potentiometer inside of the case.
Sensor replacement:	Sensor replacement switch on the interior of the CPS 10 case. Detection of sensor




CPS RM4 or RM8 Relay Module	
Dimensions (mm):	125 x 165 x 60
Mounting:	Ratchets into DIN rail
Number of relays:	4 relays (CPS RM4); 8 relays (CPS RM8) Contact type: RCT
Minimum charge for contacts:	2 A / 250 V over resistive charge
Connection:	Screw posts (cable: 2.5 mm ² max.) Torque : 0.5-0.6 Nm
Consumption:	3.5 mA in normal operation
Bistable Relays. Configuration of positive or negative relay security with mini switches. Relay modules have 2 logic inputs. Configuration via the COM_CPS configuration software.	



CPS DI16 Logic Inputs Module	
Dimensions (mm):	125 x 165 x 60
Mounting:	Ratchets into DIN rail
Number of All or Nothing Inputs:	16
Connection:	Screw posts (cable: 1.5 mm ² max.) Torque : 0.5-0.6 Nm
Consumption:	2 mA in normal operation



CPS AO4 Analog Output Module	
Dimensions (mm):	125 x 165 x 60
Mounting:	Ratchets into DIN rail
Number of analog outputs:	4-20 mA output, max. resistance 500 Ω Isolation galvanique individuelle + 2 entrées logiques
Connection:	Screw posts (cable: 1.5 mm ² max.) Torque : 0.5-0.6 Nm
Consumption under 24V at module input	< 5 mA if the 4 channels are shut down < 36 mA if only one channel is activated <130 mA if all 4 channels are activated



Chapter 8

Annexes

JBUS/MODBUS Protocol

JBUS Transfer Table

Nota : Relays and inputs are numbered from 1 to 256 and from 1 to 64. In order to optimize the occupation memory in the CPS

Classification is automatically made by the COMCPS in the ascending order of the relays then modules then lines.

idem for logic input

ADDRESS JBUS	HEXA ADDRESS
1	9C40

Access in read only by bit : Function (1 ; 2)

		BYTE							BYTE									
		B17	B16	B15	B14	B13	B12	B11	B10	B17	B16	B15	B14	B13	B12	B11	B10	B9
1	0001	Alarm Status of each detector modules																
1	0001	M32	M31	M30	M29	M28	M27	M26	M25	M24	M23	M22	M21	M20	M19	M18	M17	
2	0002	M16	M15	M14	M13	M12	M11	M10	M9	M8	M7	M6	M5	M4	M3	M2	M1	
3	0003	M32	M31	M30	M29	M28	M27	M26	M25	M24	M23	M22	M21	M20	M19	M18	M17	
4	0004	M16	M15	M14	M13	M12	M11	M10	M9	M8	M7	M6	M5	M4	M3	M2	M1	
...	...																	
15	000F	L8	M8	L8	M8	L8	M8	L8	M8	L8	M8	L8	M8	L8	M8	L8	M8	L8
16	0010	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	
17	0011	L8	M8	L8	M8	L8	M8	L8	M8	L8	M8	L8	M8	L8	M8	L8	M8	L8
33	...																	
49	0031	Alarm 3 Status of each detector module																
85	0041	Alarm 4 Status of each detector module																
81	0051	Alarm 1a11 Status of each detector module																
96	0060	Alarm 1a11 Status of each detector module																

		BYTE							BYTE									
		B17	B16	B15	B14	B13	B12	B11	B10	B17	B16	B15	B14	B13	B12	B11	B10	B9
97	0061	Relays Status (delayed one second)																
97	0061	relays 1-8	relays 9-16															
98	0062	relays 17-24	relays 25-32															
99	0063	relays 33-40	relays 41-48															
100	0064	relays 49-56	relays 57-64															
101	0065	relays ...	relays ...															
112	0070	relays 240-248	relays 249-256															
113	0071	If BIT = 0 relay OFF, If BIT = 1 relay ON																

257	0101	forced stop					Bit 7 relay24	Bit 6 relay23	Bit 5 relay22	Bit 4 relay21	Bit 3 relay20	Bit 2 relay19	Bit 1 relay18	Bit 0 relay17
257	0101	relay 1-8	relay 9-16				Bit 7 relay7	Bit 6 relay6	Bit 5 relay5	Bit 4 relay4	Bit 3 relay3	Bit 2 relay2	Bit 1 relay1	Bit 0 relay0
258	0102	relay 17-24	relay 25-32				Bit 7 relay7	Bit 6 relay6	Bit 5 relay5	Bit 4 relay4	Bit 3 relay3	Bit 2 relay2	Bit 1 relay1	Bit 0 relay0
259	0103	relay 33-40	relay 41-48				Bit 7 relay7	Bit 6 relay6	Bit 5 relay5	Bit 4 relay4	Bit 3 relay3	Bit 2 relay2	Bit 1 relay1	Bit 0 relay0
260	0104	relay 49-56	relay 57-64				Bit 7 relay7	Bit 6 relay6	Bit 5 relay5	Bit 4 relay4	Bit 3 relay3	Bit 2 relay2	Bit 1 relay1	Bit 0 relay0
261	0105	relay ...	relay ...				Bit 7 relay7	Bit 6 relay6	Bit 5 relay5	Bit 4 relay4	Bit 3 relay3	Bit 2 relay2	Bit 1 relay1	Bit 0 relay0
272	0110	relay 240-248	relay 249-256				Bit 7 relay7	Bit 6 relay6	Bit 5 relay5	Bit 4 relay4	Bit 3 relay3	Bit 2 relay2	Bit 1 relay1	Bit 0 relay0
273	0111						Bit 7 relay7	Bit 6 relay6	Bit 5 relay5	Bit 4 relay4	Bit 3 relay3	Bit 2 relay2	Bit 1 relay1	Bit 0 relay0

If bit = 0 relay under normal operating, # bit = 1 relay in forced operating

273	0111	Logic input status					Bit 7 Input 32	Bit 6 Input 31	Bit 5 Input 30	Bit 4 Input 29	Bit 3 Input 28	Bit 2 Input 27	Bit 1 Input 26	Bit 0 Input 25
273	0111	logic input 25 to 32	logic input 17 to 24				Bit 7 Input 32	Bit 6 Input 31	Bit 5 Input 30	Bit 4 Input 29	Bit 3 Input 28	Bit 2 Input 27	Bit 1 Input 26	Bit 0 Input 25
274	0112	logic input 9 to 16	logic input 1 to 8				Bit 7 Input 32	Bit 6 Input 31	Bit 5 Input 30	Bit 4 Input 29	Bit 3 Input 28	Bit 2 Input 27	Bit 1 Input 26	Bit 0 Input 25
275	0113	logic input 57 to 64	logic input 49 to 56				Bit 7 Input 32	Bit 6 Input 31	Bit 5 Input 30	Bit 4 Input 29	Bit 3 Input 28	Bit 2 Input 27	Bit 1 Input 26	Bit 0 Input 25
276	0114	logic input 41 to 48	logic input 33 to 40				Bit 7 Input 32	Bit 6 Input 31	Bit 5 Input 30	Bit 4 Input 29	Bit 3 Input 28	Bit 2 Input 27	Bit 1 Input 26	Bit 0 Input 25
277	0115						Bit 7 Input 32	Bit 6 Input 31	Bit 5 Input 30	Bit 4 Input 29	Bit 3 Input 28	Bit 2 Input 27	Bit 1 Input 26	Bit 0 Input 25

If bit = 0 disabled input, # bit = 1 enabled input

277	0115	DC supply lines and errors					Bit 8 line 8	Bit 7 line 7	Bit 6 line 6	Bit 5 line 5	Bit 4 line 4	Bit 3 line 3	Bit 2 line 2	Bit 1 line 1	Bit 0 line 0
277	0115	Alimentation line	Alimentation error				Bit 8 line 8	Bit 7 line 7	Bit 6 line 6	Bit 5 line 5	Bit 4 line 4	Bit 3 line 3	Bit 2 line 2	Bit 1 line 1	Bit 0 line 0

bit = 1 line OFF, otherwise line OK

278	0116	Fixed looms (If 1 , Ilead loon ON)	Word	Bit 15 /	Bit 14 Alarm 1 / Bit 13 High Speed Bit 12 Low speed Bit 11 Alarm 4 Bit 10 Reference Bit 9 Alarm 3 Bit 8 Fault Bit 7 Alarm 2 Bit 6 Buzzer Bit 5 Alarm 1 Bit 4 Decrease Bit 3 Alarm Bit 2 Average Bit 1 Increase Bit 0 Ok
279	0117	Blinking loon (If 1 , blinking loon ON)	Word	Word	IDEM

Access read only

Byte1

Byte2

30001	7531	overscale delay	line 1	Module 1	4 bytes (32 bits not signed)	2 bytes	16 bits de poids fort du loiq.	Bit 15
30001	7531	overscale delay	line 1	Module 1	4 bytes (32 bits not signed)	2 bytes	16 bits de poids faible du loiq.	Bit 14
30002	7532	overscale delay	line 1	Module 2		2 bytes		Bit 13
30003	7533	overscale delay	line 1	Module 3		2 bytes		Bit 12
30005	7535	overscale delay	line 1	Module 4		2 bytes		Bit 11
30007	7537	overscale delay	line 1	Module 5		2 bytes		Bit 10
30009	7539	overscale delay	line 1			2 bytes		Bit 9
...	...	overscale delay	line 2	Module 1		2 bytes		Bit 8
30065	7571	overscale delay	line 2	Module 1		2 bytes		Bit 7
...	...	overscale delay	line 3	Module 1		2 bytes		Bit 6
30129	75B1	overscale delay	line 3	Module 1		2 bytes		Bit 5
...	...	overscale delay	line 4	Module 1		2 bytes		Bit 4
30183	75F1	overscale delay	line 4	Module 1		2 bytes		Bit 3
...	...	overscale delay	line 5	Module 1		2 bytes		Bit 2
30257	7631	overscale delay	line 5	Module 1		2 bytes		Bit 1
...	...	overscale delay	line 6	Module 1		2 bytes		Bit 0
30321	7671	overscale delay	line 6	Module 1		2 bytes		
...	...	overscale delay	line 7	Module 1		2 bytes		
30385	76B1	overscale delay	line 7	Module 1		2 bytes		
...	...	overscale delay	line 8	Module 1		2 bytes		
30449	76F1	overscale delay	line 8	Module 1		2 bytes		
...	...	overscale delay	line 8	Module 32		2 bytes		
30511	772F	overscale delay	line 8	Module 32		2 bytes		
30512	7730	overscale delay	line 8	Module 32		2 bytes		

				Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
JBUS																			
30001	30C41	Detector measures																	
30001	30C41	Instantaneous measure	line 1	Module 1															
30002	30C42	Instantaneous measure	line 1	Module 2															
30003	30C43	Instantaneous measure	line 1	Module 3															
30004	30C44	Instantaneous measure	line 1	Module 4															
30005	30C45	Instantaneous measure	line 1	Module 5															
...															
30028	30C5C	Instantaneous measure	line 1	Module 28															
30029	30C5D	Instantaneous measure	line 1	Module 29															
30030	30C5E	Instantaneous measure	line 1	Module 30															
30031	30C5F	Instantaneous measure	line 1	Module 31															
30032	30C60	Instantaneous measure	line 1	Module 32															
30033	30C61	Instantaneous measure	line 2	Module 1															
30034	30C62	Instantaneous measure	line 2	Module 2															
...															
30085	30C61	Instantaneous measure	line 3	Module 1															
...															
30097	30CA1	Instantaneous measure	line 4	Module 1															
...															
30129	30CC1	Instantaneous measure	line 5	Module 1															
30161	30CE1	Instantaneous measure	line 6	Module 1															
...															
30193	30D1	Instantaneous measure	line 7	Module 1															
...															
30225	30D21	Instantaneous measure	line 8	Module 1															
...															
30256	30D40	Instantaneous measure	line 8	Module 32															
30267	30D41																		

				Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
30267	30D41	4-20mA Outputs Value (1000 = 1mA)																	
30267	30D41	Output4-20mA Value	output1																
30268	30D42	Output4-20mA Value	output2																
30269	30D43	Output4-20mA Value	output3																
30260	30D44	Output4-20mA Value	output4																
30261	30D45	Output4-20mA Value	output5																
30262	30D46	Output4-20mA Value	output6																
30263	30D47	Output4-20mA Value	output7																
30264	30D48	Output4-20mA Value	output8																
30265	30D49	Output4-20mA Value	output9																
30266	30D4A	Output4-20mA Value	output10																
30267	30D4B	Output4-20mA Value	output11																
30268	30D4C	Output4-20mA Value	output12																
...																
30512	3E40	Output4-20mA Value	output256																
30513	3E41																		

				BIT 15	BIT 14	BIT 13	BIT 12	BIT 11	BIT 10	BIT 9	BIT 8	BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
JBUS																			
40513	Detector measures																		
40514	Averaged measure 1	line 1	Module 1																
40515	Averaged measure 2	line 1	Module 1																
40516	Averaged measure 3	line 1	Module 1																
40517	Averaged measure 4	line 1	Module 1																
40518	Averaged measure 1	line 1	Module 2																
40641	Averaged measure 1	line 2	Module 1																
40642	Averaged measure 2	line 2	Module 1																
40769	Averaged measure 1	line 3	Module 1																
40887	Averaged measure 1	line 4	Module 1																
41025	Averaged measure 1	line 5	Module 1																
41153	Averaged measure 1	line 6	Module 1																
41281	Averaged measure 1	line 7	Module 1																
41409	Averaged measure 1	line 8	Module 1																
41536	Averaged measure 1	line 8	Module 32																
41537	Averaged measure 1	line 8	Module 32																

				BIT 15	BIT 14	BIT 13	BIT 12	BIT 11	BIT 10	BIT 9	BIT 8	BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
JBUS																			
41537	Detector measures																		
41538	Maximum measure	line 1	Module 1																
41539	Maximum measure	line 1	Module 2																
41540	Maximum measure	line 1	Module 3																
41541	Maximum measure	line 1	Module 4																
41542	Maximum measure	line 1	Module 5																
41564	Maximum measure	line 1	Module 28																
41565	Maximum measure	line 1	Module 29																
41566	Maximum measure	line 1	Module 30																
41567	Maximum measure	line 1	Module 31																
41568	Maximum measure	line 1	Module 32																
41569	Maximum measure	line 2	Module 1																
41570	Maximum measure	line 2	Module 2																
41601	Maximum measure	line 3	Module 1																
41633	Maximum measure	line 4	Module 1																
41665	Maximum measure	line 5	Module 1																
41697	Maximum measure	line 6	Module 1																
41729	Maximum measure	line 7	Module 1																
41761	Maximum measure	line 8	Module 1																
41792	Maximum measure	line 8	Module 32																
41793	Maximum measure	line 8	Module 32																

		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
JBUS																	
50001	C351	Module list															
50001	C351	Module 1 Name (32byte)															
		...															
50017	C361	Module type (1 byte)															
50018	C362	Relay position (1 byte)															
		Config by fault (1 byte)															
50019	C363	Module 2 Name (32byte)															
		...															
50035	C373	Module type (1 byte)															
50036	C374	Relay position (1 byte)															
		Config by fault (1 byte)															
3000		Module name 256 (32byte)															
54591	D53F	...															
3000		Module type (1 byte)															
54607	D54F	Relay position (1 byte)															
54608	D550	Config by fault (1 byte)															
54609	D551																

		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
JBUS																	
54609	D551	Relay list															
54609	D551	Module number (1byte) and relay function and position (1b)															
54610	D552	Relay Name /output 1 (20byte)															
		...															
54620	D55C	HS position /function output4-20mA (1byte) empty Byte															
54621	D55D	Module number (1byte) and Relay function and position (1b)															
54622	D55E	Relay Name /output 2 (20byte)															
		...															
54632	D568	HS Position /function output4-20mA (1byte) empty Byte															
		...															
57669	E145	Module number (1byte) and relay position and function (1b)															
		Relay Name /output256 (20byte)															
		...															
57681	E151	HS position /function output-20mA (1byte) Empty Byte															

JBUS		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
80637	EC79	Averaged alarm threshold															
80637	EC79	Averaged alarm 1 threshold															
80638	EC7A	Averaged alarm 2 threshold															
80639	EC7B	Averaged alarm 3 threshold															
		...															
80646	EC82	Averaged alarm 10 threshold															
80647	EC83	Averaged alarm 1 threshold															
80648	EC84	Averaged alarm 2 threshold															
80649	EC85	Averaged alarm 3 threshold															
		...															
80656	EC8C	Averaged alarm 2 threshold															
		...															
80676	EC90	Averaged alarm 4 threshold															

JBUS		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
80677	ECA1	Fault Alarm Threshold															
80677	ECA1	Alarm threshold															
80678	ECA2	Alarm threshold															
80679	ECA3	Alarm threshold															
		...															
80686	ECA6	Alarm threshold															

JBUS		Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
80687	ECAB	Overscale Alarm threshold															
80687	ECAB	Alarm value															
80688	ECAC	Alarm value															
80689	ECAD	Alarm value															
		...															
80696	ECB4	Alarm value															

JBUS	Bit	Bit Description	Bit Length
JBUS	80697	Averaged alarm delay	Word
	80697	ECB5 averaged alarm 1 Delay	Word
	80698	ECB6 averaged alarm 1 Delay	Word
	80699	ECB7 averaged alarm 1 Delay	Word
	80699
	80606	ECBE averaged alarm 1 Delay	Word
	80607	ECBF averaged alarm 2 Delay	Word
	80608	ECDD averaged alarm 2 Delay	Word
	80609	ECDE averaged alarm 2 Delay	Word
	80609
	80616	ECC8 averaged alarm 2 Delay	Word
	80636	ECDC averaged alarm 4 Delay	Word
	80636
	80636
	80636

JBUS	Bit	Bit Description	Bit Length
JBUS	80637	Hysteresis Value	Word
	80637	ECDD Hysteresis	Word
	80638	ECDE Hysteresis	Word
	80639	ECDF Hysteresis	Word
	80646
	80646	ECE6 Hysteresis	Word

JBUS	Bit	Bit Description	Bit Length
JBUS	80647	RESERVE COMPS	Word
	80647	ECF7	Word
	80648	ECF8	Word
	80649	ECF9	Word
	80656
	80656	ECF0	Word

JBUS	Bit	Bit Description	Bit Length
JBUS	80657	Enable or disable Alarms	Word
	80657	ECF1	Word
	80657	ECF1	Word
	80658	ECF2	Word
	80661	ECF5	Word

Bit	Bit Description	Bit Length
BIT 0
BIT 1
BIT 2
BIT 3
BIT 4
BIT 5
BIT 6
BIT 7
BIT 8
BIT 9
BIT 10
BIT 11
BIT 12
BIT 13
BIT 14
BIT 15

Bit	Bit Description	Bit Length
BIT 0
BIT 1
BIT 2
BIT 3
BIT 4
BIT 5
BIT 6
BIT 7
BIT 8
BIT 9
BIT 10
BIT 11
BIT 12
BIT 13
BIT 14
BIT 15

Bit	Bit Description	Bit Length
BIT 0
BIT 1
BIT 2
BIT 3
BIT 4
BIT 5
BIT 6
BIT 7
BIT 8
BIT 9
BIT 10
BIT 11
BIT 12
BIT 13
BIT 14
BIT 15

	BIT 15	BIT 14	BIT 13	BIT 12	BIT 11	BIT 10	BIT 9	BIT 8	BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
JBUS																
80662	Checking of the type of connected detector															
80662	Type 1 (1 byte)															
80663	Type 2 (1 byte)															
80663	Type 3 (1 byte)															
80663	Type 4 (1 byte)															
80666	...															
80666	Type 9 (1 byte)															
80666	Type 10 (1 byte)															
80666	Code detector type 1															
80666	Code detector type 2															
80666	Code detector type 3															
80666	Code detector type 4															
80666	Code detector type 9															
80666	Code detector type 10															

	BIT 15	BIT 14	BIT 13	BIT 12	BIT 11	BIT 10	BIT 9	BIT 8	BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
JBUS																
80667	Gas name															
80667	Gas name for type 1 (5 bytes)															
80667	Norm 1 Byte 2															
80669	...															
80669	Gas name for type 1 and 2 (5 bytes)															
80670	Gas name for type 2 (5 bytes)															
80670	name 2 Byte 1															
80671	Gas name for type 2 (5 bytes)															
80671	name 2 Byte 3															
80671	name 2 Byte 4															
80671	name 2 Byte 5															
80671	...															
80671	Gas name for type 10 (5 bytes)															
80671	name 10 Byte 4															
80671	name 10 Byte 5															

	BIT 15	BIT 14	BIT 13	BIT 12	BIT 11	BIT 10	BIT 9	BIT 8	BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
JBUS																
80714	Gas shortened name															
80692	Gas name for type 1 (16 bytes)															
80692	Name 1 Byte 2															
80699	...															
80699	Gas name for type 2 (16 bytes)															
80699	Name 2 Byte 1															
80699	Name 2 Byte 2															
80699	...															
80771	Gas name for type 10 (16 bytes)															
80771	Name 10 Byte 15															
80771	Name 10 Byte 16															

	BIT 15	BIT 14	BIT 13	BIT 12	BIT 11	BIT 10	BIT 9	BIT 8	BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
JBUS																
80772	Display format															
80772	Type 1 (1 byte)															
80772	Display format code type 1															
80773	Type 2 (1 byte)															
80773	Display format code type 2															
80773	Type 3 (1 byte)															
80773	Display format code type 3															
80773	Type 4 (1 byte)															
80773	Display format code type 4															
80776	...															
80776	Type 9 (1 byte)															
80776	Display format code type 9															
80776	Type 10 (1 byte)															
80776	Display format code type 10															

0 = Integer, 1 = digit after the point (0.0), 2 = 2 digits after the point (0.00)

		BIT 0	BIT 1	BIT 2	BIT 3	BIT 4	BIT 5	BIT 6	BIT 7	BIT 8	BIT 9	BIT 10	BIT 11	BIT 12	BIT 13	BIT 14	BIT 15
JBUS																	
30787	ED73	Reserve COMCIPS															
30787	ED73	Type 1 (1 byte)															
30788	ED74	Type 2 (1 byte)															
		Type 3 (1 byte)															
		...															
30791	ED77	Type 9 (1 byte)															
		Type 10 (1 byte)															

		BIT 0	BIT 1	BIT 2	BIT 3	BIT 4	BIT 5	BIT 6	BIT 7	BIT 8	BIT 9	BIT 10	BIT 11	BIT 12	BIT 13	BIT 14	BIT 15
JBUS																	
30792	ED78	Alarm Delay															
30792	ED78	Alarm 1 Delay															
30793	ED79	Alarm 2 Delay															
30794	ED7A	Alarm 3 Delay															
		...															
30801	ED81	Alarm 1 Delay															
30802	ED82	Alarm 2 Delay															
30803	ED83	Alarm 3 Delay															
30804	ED84	Alarm 4 Delay															
		...															
30811	ED8B	Alarm 2 Delay															
		...															
30831	ED9F	Alarm 4 Delay															

		BIT 0	BIT 1	BIT 2	BIT 3	BIT 4	BIT 5	BIT 6	BIT 7	BIT 8	BIT 9	BIT 10	BIT 11	BIT 12	BIT 13	BIT 14	BIT 15
JBUS																	
30832	EDA0	Detector type Range															
30832	EDA0	Range															
30833	EDA1	Range															
30834	EDA2	Range															
		...															
30841	EDA9	Range															

Chapter 9 UE Declaration of Conformity



DECLARATION UE DE CONFORMITE
EU Declaration of Conformity



La société Oldham S.A.S., ZI Est 62000 Arras France, atteste que la
Oldham S.A.S. company, ZI Est 62000 Arras France, declares that the

Système de mesure CPS –Monitoring system CPS

Incluant la centrale de mesure, les détecteurs de gaz, les modules E/S et relais
Including the controller, the gas detectors, the relays and I/O modules

est conforme aux exigences de:
complies with the requirements of the following Directives:

I) Directive Européenne CEM 2014/30/UE du 26/02/14: Compatibilité Electromagnétique
The European Directive EMC 2014/30/UE dated from 26/02/14: Electromagnetic Compatibility

Normes harmonisées appliquées: EN 50270:06 for type 1&2 CEM-Appareils de détection de gaz
Harmonised applied Standards EMC-Apparatus for the detection of gases

II) Directive Européenne DBT 2014/35/UE du 26/02/14: Basse Tension
The European Directive LVD 2014/35/UE dated from 26/02/14: Low Voltage

Normes harmonisées appliquées: EN 61010-1:10 Règles de sécurité pour appareils
Harmonised applied Standard électriques de mesurage
Safety requirements for electrical equipment for measurement

III) Norme de performance métrologique
Metrology Performance Standard

Normes appliquée VDI 2053:04, Annex2,
Applied Standard Mesure du CO (CO measurement)

Organisme certificateur TÜVRheinland® (Köln, Germany)
Certification Body
Prüfungsbüro

Rapport d'essai S274 2007 T1
Test Report

Arras, le 20/04/2016 (April 20th, 2016)

Michel Spellemaecker



Oldham S.A.S.
Z.I. EST - C.S. 20417
62027 ARRAS Cedex – FRANCE
Tel. : +33(0)3 21 60 80 80
www.oldhamgas.com




Global Director of Product Management

UE_CPS_revA



EUROPEAN PLANT AND OFFICES

Z.I. Est – rue Orfila CS 20417 – 62027 Arras Cedex FRANCE

Tél: +33 (0)3 21 60 80 80 – Fax: +33 (0)3 21 60 80 00

Website: <https://gasdetection.3M.com>

AMERICAS

Tel: +1 713-559-9280

Fax: +1 281-292-2860

americas@oldhamgas.com

ASIA PACIFIC

Tel: +86-21-3127-6373

Fax: +86-21-3127-6365

sales@oldhamgas.com

EUROPE

Tel: +33-321-608-080

Fax: +33-321-608-000

info@oldhamgas.com