

QUICK REFERENCE GUIDE



OmniPoint™
Universal Transmitter


Honeywell

Product Description


The OmniPoint™ transmitter is a comprehensive gas detection solution designed to operate in hazardous locations and support multiple sensors in detecting toxic, oxygen, and flammable gas hazards. OmniPoint utilizes multiple sensor technologies to meet diverse gas detection challenges in various global industries. Full color, touch key interface, and optional Bluetooth-enabled operation make setup and maintenance intuitive. Support for up to three sensors makes OmniPoint flexible and scalable to meet your safety requirements.

Transmitter overview

Aperçu de l'émetteur, Übersichts Transmitter, Panoramica del trasmettitore, Visão geral do transmissor, Descripción general del transmisor




- Full-color TFT LCD with four touch keys.** LCD TFT couleur avec quatre touches tactiles, Farbiges TFT-LCD mit vier Touch-Tasten, Display LCD TFT a colori con quattro touch key, LCD TFT colorido com quatro telas sensíveis ao toque, TFT LCD a color con cuatro telas tactiles.
- Ergonomic bevel and curved design for easier operation.** Biseau ergonomique et conception incurvée pour une utilisation plus facile, Ergonomische Abschrägung und geschwungenes Design zur einfacheren Bedienung, Design curve ed ergonomico per una maggiore praticità di utilizzo, Bisel ergonomico e design curvo para facilitar a operação, Bisel ergonomico y diseño curvo para una operación más sencilla.
- Elliptical race-track-screw holes to maximize the fit of four M8 screws.** Trous de vis elliptiques pour maximiser l'ajustement des quatre vis M8, Elliptenförmige Schraubenlöcher für optimalen Sitz von vier M8-Schrauben, Fori ellittici per un miglior fissaggio tramite quattro viti M8, Orifícios para parafusos elípticos em formato de pista para maximizar o ajuste de quatro parafusos M8, Orifícios de circuito elíptico para que los cuatro tornillos M8 encajen correctamente.
- Five M25 (P/N 3021D0397) or 3/4" NPT (P/N 3021D1505) entries (Antenna port excluded). The stopping plugs supplied (Honeywell P/N 1226-0258) are approved only for the OmniPoint universal transmitter.** Cinq entrées M25 (P/N 3021D0397) o NPT de 3/4" (P/N 3021D1505) (excluse l'attacco dell'antenna). I tappi di arresto forniti (Honeywell P/N 1226-0258) sono approvati solo per il trasmettitore universale OmniPoint. Cinco entradas para M25 (P/N 3021D0397) - oder 3/4"-NPT-Zuführungen (P/N 3021D1505) (Anschluss für Antenne ausgenommen). Die mitgelieferten Verschlussstopfen (Honeywell P/N 1226-0258) sind nur für den OmniPoint-Universalsender zugelassen. Cinq entrées M25 (P/N 3021D0397) o NPT de 3/4" (P/N 3021D1505) (excluse l'attacco dell'antenna). I tappi di arresto forniti (Honeywell P/N 1226-0258) sono approvati solo per il trasmettitore universale OmniPoint. Cinco entradas para M25 (P/N 3021D0397) ou 3/4 pol (P/N 3021D1505). NPT (porta de antena excluída). Os plugues de fechamento fornecidos (Honeywell P/N 1226-0258) são aprovados apenas para o transmissor universal OmniPoint. Cinco entradas M25 (P/N 3021D0397) o NPT de 3/4" (P/N 3021D1505) (se excluye el puerto para antena). Los tapones de cierre suministrados (Honeywell P/N 1226-0258) están aprobados solo para el transmissor universal OmniPoint.
- Top enclosure set screw.** Vis de réglage du boîtier supérieur, Oberer Stellschraube für das Gehäuse, Vite di fermo dell'alloggiamento superiore, Parafusos do topo da carcaça, Tornillo de fijación del gabinete superior.
- Earth/ground point.** Point de mise à la terre/masse, Erdungspunkt, Earth/ground point, Punto di messa a terra, Ponto de terra/aterramento, Punto de conexión a tierra.
- Bluetooth Antenna (optional) P/N 3021D0399** Antenna Entry M22 is only used for the Bluetooth feature with the antenna module. It is not intended for other connections. Use the M22 plug when not in use. Bluetooth-Antenne (optional) P/N 3021D0399. Der Antennenanschluss M22 wird nur für die Bluetooth-Funktion mit dem Antennenmodul verwendet. Für andere Anschlüsse ist es nicht vorgesehen. Verwenden Sie den M22-Stecker, wenn Sie ihn nicht verwenden. Antenna Bluetooth (opcional) P/N 3021D0399. L'ingresso antenna M22 viene utilizzato solo per la funzionalità Bluetooth con il modulo antenna. Non è destinato ad altri collegamenti. Utilizzare la spina M22 quando non in uso. Antenne Bluetooth (en option) P/N 3021D0399. L'entrée d'antenne M22 est utilisée uniquement pour la fonction Bluetooth avec le module d'antenne. Il n'est pas destiné à d'autres connexions. Utilisez la fiche M22 lorsqu'elle n'est pas utilisée. Antena Bluetooth (opcional) P/N 3021D0399. A entrada de antena M22 é usada apenas para o recurso Bluetooth com o módulo de antena. Não se destina a outras conexões. Use o plugue M22 quando não estiver em uso. Antena Bluetooth (opcional) P/N 3021D0399. La entrada de antena M22 solo se usa para la función Bluetooth con el módulo de antena. No está destinado a otras conexiones. Utilice el enchufe M22 cuando no esté en uso.



What's in a Full System Box

1 Quick Reference Guide	3 Terminal blocks	1 Screwdriver
1 M22 plug or BLE (optional)	1 Calibration Cap	1 Allen Wrench
3 Plugs 3/4" NPT or M25	1 Transmitter	

Sensor & Local Hart Interface



- XPIs/XP** Thread cap, Bouchon fileté, Gewindehapter, Cappuccio della filettatura, Tampa de rosca, tapa rosca
- Local Hart Interface** Metal cap, Metal cap, Capuchon métallique, Metalladaptor, Cappuccio metallico, tampa de metal, tapa metálica.


Certifications and Approvals

Hazardous Area Approvals (Transmitter/Sensor Dependent)
UL: cUL, classified, UL 1203, UL 313, UL 51010-1, CSA C22.2 No. 25, CSA C22.2 No. 30, CSA C22.2 No. 60079-0, CSA C22.2 No. 60079-11, CAN/CSA-C22.2 No. 61010-1-12, Class I, Division 1, Groups A, B, C & D, T5, Class II, Division 1, Groups F & G T4A

EU Directive 2012/19/EU: Waste Electrical and Electronic Equipment (WEEE) This symbol indicates that the product must not be disposed of as general industrial or domestic waste. This product should be disposed of through suitable WEEE disposal facilities. For more information about the disposal of this product, contact your authority, distributor, or manufacturer.

User Interface overview

Aperçu de l'interface utilisateur, Übersicht über die Benutzeroberfläche, Panoramica dell'interfaccia utente, Visão geral da interface do usuário, Descripción general de interfaz de usuario.



Number	Description
1	The LED light ring and Badge show the transmitter's running state. L'anneau lumineux à DEL et le badge indiquent l'état de fonctionnement de l'émetteur. Der LED-Leuchtring und die Plakette zeigen den Betriebszustand des Transmitters. L'anello luminoso e il badge LED indicano lo stato di funzionamento del trasmettitore. O anel de luz LED e o emblema mostram o estado de funcionamento do transmissor. La luz LED y la insignia muestran el estado de ejecución del transmisor.


	Touch keys, Touches tactiles, Toccare il tasto, Teclas, Menü, Increase/Decrease, Augmentation/Diminution, Erhöhen/Verringern, Aumento/Riduzione, Aumentar/diminuir, Aumentar/Disminuir.	Increase/Decrease, Augmentation/Diminution, Erhöhen/Verringern, Aumento/Riduzione, Aumentar/diminuir, Aumentar/Disminuir.
1	Information, Renseignements, Informations, Informaciones, Informações, Información.	Navigation, Naviguer, Navigieren, Navigazione, Navigieren.
2	Selection, Sélection, Auswahl, Selezione, Seleção, Selección.	Reset, Réinitialiser, Zurücksetzen, Azzeramento, Redefinir, Reiniciar.
3	Return, Retour, Eingabe, Voltar, Regresar.	Alarm Snapshot, Instantané d'alarme, Alarm-Snapshot, Snapshot allarme, Captura de alarme, Instantánea de la alarma.
4	Alarm Relay Acknowledge, Acquiescement du relai d'alarme, Alarml relais bestätigen, Acquisizione rele allarme, Confirmação de relé de alarme, Reconocimiento del retrasmisor de la alarma.	

3	Gas readings with gas type and measuring unit, Lectures de gaz avec type de gaz et unité de mesure, Gasmesswerte mit Gastype und Maßeinheit, Letture gas con tipologia e unità di misura, Leituras de gas com tipo de gás e unidade de medição, Lecturas del gas con tipo de gas y unidad de medida.
4	Icons, Icônes, Anzeigensymbole, Icone, Icones, icono: - Option module (BLE, MODBUS RTU) installation state, État d'installation du module d'option (BLE, MODBUS RTU), Installationszustand des Optionsmoduls (BLE, MODBUS, RTU), Stato di installazione modulo opzionale (BLE, MODBUS RTU), Estado de instalação do módulo opcional (BLE, MODBUS RTU), Estado de instalación del módulo opcional (BLE, MODBUS RTU). - Channel information (order), Informations sur le cana, Kanalinformationen (Reihenfolge), Informazioni sui canali (ordine), Informações do canal (pedido), Información del canal (orden). - Sensor changing indicator, Indicateur de changement de détecteur, Anzeige für Sensorwechsel, Indicatore di sostituzione sensore, Indicador de mudança de sensor, Indicador del cambio de sensor. - Bump/calibration overdue indicator, Indicateur de test fonctionnel/étalonnage en retard, Anzeige für Fälligkeit von Funktions-test/Kalibrierung, Indicatore intervallo impatto/taratura, Indicador de teste geral/calibração atrasada, Indicador de vencimiento de calibración/prueba funcional.

Status, Statut, Stato.	LED Light Ring, Anneau lumineux à DEL, LED-Leuchtring, Anello luminoso LED, Anel de luz LED, Anillo de luz LED.	Red, Rouge, Rot, Rosso, Vermelho, Rojo.	Green, Vert, Grün, Verde.	Yellow, Jaune, Gelb, Giallo, Amarilla, Amarillo.	Blue, Bleu, Blau, Blu, Azul.
Inhibit, Inhibier, Sperren, Inibizione, Inibição.		Flashing alternately green & yellow, Clignotant alternativement vert et jaune, Blinkt abwechselnd grün und gelb, Intermittenza alternata verde e giallo, Piscando alternadamente em verde e amarelo, Intermitente alternando entre verde y amarillo.			
Alarm 2, Alarme 2.	Flashing, Clignotant, Blinkt, Intermittenza, Intermitente.				
Alarm 1, Alarma 1.	Solid, Fixe, Leuchtet konstant, Fisso, Continuo, Fijo.				
Fault, Anomalie, Fehler, Errore, Falha, Falla.			Flashing, Clignotant, Blinkt, Intermittenza, Intermitente.		
Warning, Avertissement, Warnung, Attenzione, Aviso, Advertencia.					
Warm-up, Prechauffage, Aufwärmen, Riscaldamento, Aquecimento, Calentamiento.		Flashing alternately green & yellow, Clignotant alternativement vert et jaune, Blinkt abwechselnd grün und gelb, Intermittenza alternata verde e giallo, Piscando alternadamente em verde e amarelo, Intermitente alternando entre verde y amarillo.			
Normal, Normale.		Solid (default), Solide (par défaut), Leuchtet konstant (Standardinstallation), Fisso (predefinito), Continuo (padrão), Fijo (predefinido).			
Bluetooth connected, Bluetooth connecté, Bluetooth-connect, Bluetooth-Verbindung, Bluetooth ligado, Bluetooth conectados.					Solid, Fixe, Leuchtet konstant, Fisso, Continuo, Fijo.
Transmitter Updating, Mise à jour de l'émetteur, Transmitter wird aktualisiert, Aggiornamento trasmettitore, Atualização de transmissor, Actualización del transmisor.		Flashing alternately red & green, Clignotant alternativement vert et rouge, Blinkt abwechselnd rot und grün, Intermittenza alternata rosso e verde, Piscando alternadamente em vermelho e verde, Intermitente alternando entre rojo y verde.			

Mounting the Transmitter


The transmitter can be attached to flat wall surfaces of various types or pipes using the optional Pipe Mount Kit.



The transmitter is configured with five cable/conduit ports built into the housing for wiring and mounting sensors. For relay wiring, please refer to the User Manual. Drill 4X holes corresponding to the appropriate hardware from the following chart.


Mounting hardware			
Mounting surface	Example part	Description	Drill bit size
Drywall, plaster, wood paneling	McMaster-Carr 97121A043 (Quantity: 4 each) In the case of McMaster-Carr 90107A029 (Quantity: 4 each)	Rounded Head Toggle Bolt - Thread 1/4in - 20 - Length 3in 2-1/8in Wing-Span Toggle - Pull-out Strength: 500lbs - Shear Strength: 50 lbs 316 Stainless Steel Washer - For screw 1/4in - ID 0.281in / OD 0.625in / Thickness 0.043in-0.057in	5/8in
Concrete	McMaster-Carr 97083A210 (Quantity: 4 each) And McMaster-Carr 90272A540 (Quantity: 4 each) In case McMaster-Carr 90107A029 (Quantity: 4 each)	Steel Female-Threaded Anchor for Concrete - Thread 1/4in - 20 - Length 1in - Shear Strength: 495 lbs - Shear Strength: 530lbs - Zinc-Plated Steel Pan Head Phillips Screw - Thread 1/4in - 20, Length 3/4in 316 Stainless Steel Washer - For screw 1/4in - ID 0.281in / OD 0.625in / Thickness 0.043in-0.057in	3/8in

Wiring for Power




Ensure that sufficient power is supplied: 24 Vdc is required. Circuits are limited to overvoltage category III or less. Use wire size 30 - 12 AWG and tightening torque of 5 - 7 Lb-in.

mA Output Mode






For MODBUS - Use wire size 30 - 12 AWG and tightening torque of 5 - 7 Lb-in.


Relay Wiring



Use wire size 30 - 12 AWG and tightening torque of 5 - 7 Lb-in.




XP and XPIs Sensor to TX Wiring




Ensure sensors are installed to the transmitter with a min. 30Nm / MIN 266lbf in. Use wire size 30-14 AWG and tightening torque of 2 - 2.2 Lb-in

Optima to TX Wiring




Wire Color	Connection	Purpose
Red	+24 Vdc	+ve Supply
Black	0 Vdc	-ve Supply
White	4-20 mA Output	Signal
Orange	RS485 A	Communication
Blue	RS485 B	Communication
Green/Yellow	Earth	Protective Earth

Remote Mount Sensor Configuration



For NPT Threads configuration, ensure a minimum engagement of 5; for Metric Threads configuration, ensure a minimum engagement of 8. Honeywell recommends using Akron Electric INC., Part Nos. 2430-0021 and 2441-0022 Junction Boxes. Ensure use of appropriate junction box per local requirements.

Grounding and EMI





Internal ground connection: Utilize the shield of the wiring cable recommended in the wiring instructions. For connection to this terminal, twist the shield wire to avoid stray shield wires. Loosen the screw sufficiently and wrap the wire around the screw in a "U" shape. Raise the clamp and place the wire between the clamp and ground base, lower the clamp, and tighten the screw for a torque of 6.9 lb-in. External ground connection: If local authority requires, utilize at least 4mm² copper (stranded or solid) wire. Loosen the screw sufficiently to enable wrapping the wire around the screw in a "U" shape. Raise the clamp and place the wire between the clamp and ground base, lower the clamp, and tighten the screw to a torque of 10.4 lb-in. Supplemental external bonding terminal should not be used in North American installations unless local authorities permit.

CAUTION: Any earthing regime employed must avoid earth loops.

The following information is provided to assist with proper earthing of the OmniPoint:

- The OmniPoint provides both internal and external earth ground points. This facilitates connecting the detector to the protective earth.
- The internal earth shall be used for the equipment grounding connection. It must be at least equal in mm² to the incoming power conductors.
- The EXTERNAL earth provides a supplementary bonding connection, which allows for the connection of field wiring conductors of at least 4mm².

Wiring the Transmitter



- Install in accordance with local electrical codes.
- Follow the warnings and requirements on the junction box for proper seals in the conduit as required.
- To reduce the risk of ignition in hazardous atmospheres, conduit runs must have a seal fitting connected within 18in. of the enclosure (Only for XPIs Sensor).
- Do not open in an explosive atmosphere.
- Do not open or separate when energized.
- Potential electrostatic charging hazard - See the OmniPoint User Manual for instructions.

Clean the product only with a damp cloth.

RISK OF EXPLOSION

High off-scale readings may indicate an explosive gas concentration

CAUTION	
RISK OF IGNITION	
To reduce the risk of ignition in hazardous atmospheres, disconnect the equipment from the supply circuit before opening the enclosure. Keep tightly closed when in operation. RISK OF INJURY, IMPROPER OPERATION, EQUIPMENT DAMAGE, AND INVALIDATION OF WARRANTY	
Install in accordance with local electrical codes.	
Relevant standards must be followed to maintain the overall certification of the detector.	
Only use with Honeywell replacement parts and accessories.	
Never open system devices under power unless the area is known to be non-hazardous.	
The internal grounding terminal shall be used as the equipment grounding means. The external terminal is only a supplemental bonding connection where local authorities permit or require it.	
Periodic checks are recommended to verify the safety and integrity of the system.	
For optimal performance, periodically zero the sensor in a normal atmosphere (20.9% v/v O2) that is free of hazardous gases.	
As some test gases are hazardous, exhaust the flow housing outlet to a safe area.	
All unused and used cable/conduit entries must be sealed with a suitable certified sealing plug and cable gland.	
Use only certified 3/4" or M25 cable glands for installation.	
Use copper conductors only.	

Specific Conditions of Use

Potential Electrostatic Discharge - Clean the product only with a damp cloth.

Operating Conditions

This equipment is intended for use under the following conditions


Environment:	- Temperature: -55°C ± Tamb ± 75°C / -67°F ± Tamb ± 167°F (transmitter) - Humidity: 5 to 95% RH non-condensing (transmitter) - Altitude less than 2000m - Indoor use for UL/CSA 61010-1
IP Rating:	NEMA AXIP66/67
Operating Voltage:	12-32 Vdc (24 Vdc Nominal) XP (mV, mA) and XPIs (ECC) sensors 18-32 Vdc (24 Vdc Nominal) Optima - Overvoltage Category II (UL/CSA 61010-1)
Power Consumption:	- Transmitter: Normal 4.5 watts, Max 8.5 watts - XPIs sensor (EC cell): Max 0.3 watts - XP sensor (Catalytic or IR cell): Max 1.7 watts - Optima ± 2 XP (CB) sensors: 1.7 watts
Point Infrared sensor (Searchpoint Optima):	- Max 13.0 watts (Transmitter + Optima) - Transmitter: typ 4.5 watts, max 8.5 watts - Optima: max 4.5 watts

Web app and Bluetooth

Connecting to a detector via Bluetooth To pair your smartphone with a specific detector, follow these steps:

- Download the OmniPoint app from Google Play Store, install and launch the app.
- Create and register a user account, and log on with the created account information.
- Associate with one or more gas detectors, scan the QR code on the sheet included in the box or enter its Activation Key.
- Complete the installation of the detectors.
- On the app's home screen, tap DETECTORS to scan for available detectors.
- Select a detector from the detector list to pair with it.
- Look for the detector whose status indicator is flashing blue.
- Tap Confirm to pair with that detector. Otherwise, tap Return to List to select one of the others.

Configuration



OmniPoint may be fitted with the following:

- XP (Cat bead and IR)
- XPIs (Electrochemical)
- Optima (Hydrocarbon Point IR)
- Local Hart Port

Any cable entry other than the top can be used for power or sensor connections. OmniPoint is a gas detection system. When assessing the overall system rating, please consult the rating of each component.

- Please ensure the suitability of all components for the application.
- Please consult the rating of each component in the system and the overall suitability for the application.

Contact Us

Europe, Middle East, Africa: Life Safety Distribution GmbH Javastrasse 2 8504 Hegnau Switzerland Tel: +41 (0)44 963 4300 gastetection@honeywell.com	Americas: Honeywell Analytics Distribution Inc. 405 Barclay Blvd Lincolnshire, IL 60069 USA Tel: +1 847 955 9200 Toll-free: +1 800 538 0363 detecgas@honeywell.com	Technical Services EMEA: gastechsupport@honeywell.com Americas: is.gas.techsupport@honeywell.com AP: gastechsupport.apac@honeywell.com LATAM: SupportTecnicoHGAS@honeywell.com	Scan this code for further reference to the Honeywell website Quick Reference Guide3021M5001 Language: English Revision A 1/2/2025 © 2024 Honeywell International INC. automation.honeywell.com
--	--	---	---

