


Gasurveyor 500 PPM

QUICK OPERATING INSTRUCTIONS











Gasurveyor 500 PPM

QUICK OPERATING INSTRUCTIONS







∑ Single Press

∇ Double Press

CGI MODE (PPM / LEL / Vol. GAS - Autoranging)

Switch ON:



OR **T** LOG



Switch OFF:





To abort, press any button.

Pump Operation:

'SAMPLE' displayed when pump is ON.



- toggles pump OFF & ON.

Sample Fault:

Clear blockage. To restart pump:





Manual Datalog:

'STORE' displayed when datalogging.





Zero PPM Range:



- only to be carried out in fresh air.