

MODEL IR4000S SINGLE POINT MONITOR



IR4000S- 0 - 0 - 0 2 - 1 - 0 - 1

SINGLE POINT MONITOR

(Std) SINGLE POINT MONITOR

A. MONITOR OUTPUT:

0- (Std) IR400/IR2100 (0-100 RANGE)

B. RELAY-STATE-NC:

- 0- (Std) NO RELAYS
- 1- LATCH ALARM/NON-LATCH WARN DE-ENERGIZED
- 2- LATCH ALARM/NON-LATCH WARN ENERGIZED
- 3- LATCH ALARM/LATCH WARN DE-ENERGIZED
- 4- LATCH ALARM/LATCH WARN ENERGIZED
- 5- NON-LATCH ALARM/NON-LATCH WARN DE-ENERGIZED
- 6- NON-LATCH ALARM/NON-LATCH WARN ENERGIZED
- 7- NON-LATCH ALARM/LATCH WARN DE-ENERGIZED
- 8- NON-LATCH ALARM/LATCH WARN ENERGIZED

C. DETECTOR:

- 00- NO DETECTOR
- 01- IR400-0-01-1-1-0-1-0 METHANE, NO SCREEN, ALUMINUM
- 02- (Std) IR400-0-01-1-2-0-1-0 METHANE, SCREEN, ALUMINUM
- 03- IR400-0-01-2-1-0-1-0 METHANE, NO SCREEN, STAINLESS STEEL
- 04- IR400-0-01-2-2-0-1-0 METHANE, SCREEN, STAINLESS STEEL
- 05- IR400-0-02-1-1-0-1-0 PROPANE, NO SCREEN, ALUMINUM
- 06- IR400-0-02-1-2-0-1-0 PROPANE, SCREEN, ALUMINUM
- 09- IR400-0-04-1-2-0-1-0 HEXANE, SCREEN, ALUMINUM
- 13- IR400-4-01-2-2-0-1-0 METHANE, SCREEN, STAINLESS STEEL, HART, USED W/IR4000S
- 21- IR400-4-01-1-2-0-1-0 METHANE, SCREEN, ALUMINUM, HART, USED W/IR4000S
- 22- IR400-4-02-1-2-0-1-0 PROPANE, SCREEN, ALUMINUM, HART, USED W/IR4000S
- 23- IR400-4-04-1-2-0-1-0 HEXANE, SCREEN, ALUMINUM, HART, USED W/IR4000S
- 24- IR400-4-05-1-2-0-1-0 PENTANE, SCREEN, ALUMINUM, HART, USED W/IR4000S
- 25- IR400-4-07-1-2-0-1-0 BUTANE, SCREEN, ALUMINUM, HART, USED W/IR4000S
- 45- IR400-4-07-2-2-0-1-0 BUTANE, SCREEN, STAINLESS STEEL, HART, USED W/IR4000S

D. CONNECTOR TYPE:

- 1- (Std) PUSH TERMINAL
- 2- SCREW TERMINAL

E. JUNCTION-BOX

- 0- (Std) NO J-BOX
- 1- 31305-1 JUNCTION BOX W/SWITCH
- 2- 31305-2 JUNCTION BOX W/O SWITCH
- 6- 31421-6 ASSEMBLY, EUROPEAN, JUNCTION BOX W/O SWITCH
- 7- 31421-5 ASSEMBLY, EUROPEAN, JUNCTION BOX W/SWITCH, SST

F. APPROVALS/LANGUAGE/HOUSING MATERIAL

- 1- (Std) ALUMINUM HOUSING
- 4- STAINLESS STEEL HOUSING
- 8- GREY, NO ZINC SST

Notes: See Toxic section for IR700 configurations w/IR4000S-CO2 version.