

QUICK START GUIDE

AcustiCal AC-300 Calibrator







On/Off/Enter key

- + Press to power on
- + Press again to change to 250 Hz if applicable
- + Press to power off

TS | **QUEST**™

Calibration

1. Insert the microphone (with the cal adapter if needed) into the calibrator cavity ensuring the microphone and adapter are fully seated (or inserted).
Note: the ambient noise level should be less than 88 dBA.
2. Power on the AcoustiCal by pressing the  key and allow at least 10 seconds to stabilize.
 - + 1000 Hz at 114 dB will be displayed.
 - + If setting to 250Hz at 114 dB, press  key.
3. Perform the calibration.
 - + Reference the instrument's user manual for additional details.
4. To power off, press the  key.
Note: an auto-power off will occur after 4 minutes from the last key press.
5. Press and hold the  key for 2 seconds (approximately) to power off.



Quest is a trademark, and TSI and the TSI logo are registered trademarks of TSI Incorporated.

